

**FASTCHECK AIRBAG**

Make	Model	From/To	System	Harness Required
Alfa Romeo	145	94 - 98	TRW2	OM3000/10 or OM3000/10 + OG2023
Alfa Romeo	145	94 - 00	TRW MY97	OM3000/10 or OM3000/10 + OG2023
Alfa Romeo	146	94 - 98	TRW2	OM3000/10 or OM3000/10 + OG2023
Alfa Romeo	146	95 - 00	TRW MY97	OM3000/10 or OM3000/10 + OG2023
Alfa Romeo	147	00 - 04	Allied MY97	OM3000/10
Alfa Romeo	147	00 - 07	Siemens MY99	OM3000/10
Alfa Romeo	156	97 - 02	Allied MY97, Allied Signal, Allied Signal 2	OM3000/10 or OM3000/10 + OG2023
Alfa Romeo	156 '02	02 - 05	Siemens MY99	OM3000/10
Alfa Romeo	159	05 -	TRW MY03	OM3000/10
Alfa Romeo	166	98 - 03	TRW MY97, TRW MY99	OM3000/10 or OM3000/10 + OG2023
Alfa Romeo	Brera	05 -	TRW MY03	OM3000/10
Alfa Romeo	GT	04 -	Siemens MY99	OM3000/10
Alfa Romeo	GTV	95 - 98	TRW2 Airbag w/pretensioners	OM3000/10 or OM3000/10 + OG2023
Alfa Romeo	GTV	97 - 03	TRW MY97	OM3000/10 or OM3000/10 + OG2023
Alfa Romeo	MiTo	08 -	SIEMENS Airbag (EP-Proxi)	OM3000/10
Alfa Romeo	Spider	95 - 98	TRW2 Airbag w/pretensioners	OM3000/10 or OM3000/10 + OG2023
Alfa Romeo	Spider (939)	07 -	TRW MY03	OM3000/10
Audi	80/Cabrio/Coupe/Quattro	94 - 96	KWP1281	OM3000/10 + OG2022
Audi	A2	00 - 04	KWP1281/KW2000	OM3000/10
Audi	A3	96 - 04	KWP1281/KW2000	OM3000/10
Audi	A3	04 -	CAN	OM3000/10
Audi	A4	95 - 04	KWP1281/KW2000	OM3000/10
Audi	A4	04 -	CAN	OM3000/10
Audi	S4	95 - 04	KWP1281/KW2000	OM3000/10
Audi	S4	04 -	CAN	OM3000/10
Audi	A5	08 -	CAN	OM3000/10
Audi	S5	08 -	CAN	OM3000/10
Audi	A6	97 - 04	KWP1281/KW2000	OM3000/10
Audi	A6	04 -	CAN	OM3000/10
Audi	S6	97 - 04	KWP1281/KW2000	OM3000/10
Audi	S6	04 -	CAN	OM3000/10
Audi	Allroad Quattro	01 - 04	KWP1281/KW2000	OM3000/10
Audi	Q7	06 -	CAN	OM3000/10
Audi	A8	94 - 04	KWP1281/KW2000	OM3000/10
Audi	A8	04 -	CAN	OM3000/10
Audi	S8	94 - 04	KWP1281/KW2000	OM3000/10
Audi	S8	04 -	CAN	OM3000/10
Audi	TT	98 - 07	KWP1281/KW2000	OM3000/10
Audi	TT	07 -	CAN	OM3000/10
Audi	100	94 - 97	KWP1281/KW2000	OM3000/10 + OG2022
BMW	1 Series (E81/E87)	04 - 03/07	MRS5	OM3000/10
BMW	1 Series (E81/E82/E87/E88)	03/07 -	MRS5 (CAN), ACSM (CAN)	OM3000/10
BMW	3 Series (E30)	91 - 93	Driver Airbag (5WK4 060)	OM3000/10 + OG2002
BMW	3 Series (E36)	90 - 98	ZAE BAE, ZAE2, MRS 1, MRS 2, MRS 3	OM3000/10 or OM3000/10 + OG2002
BMW	3 Series (E36)	91 - 93	Driver Airbag (5WK4 060)	OM3000/10 + OG2002
BMW	3 Series (E36)	93 - 95	1 or 2 airbags (ZAE, BAE)	OM3000/10 + OG2002
BMW	3 Series (E46)	98 - 05	MRS 3, MRS 4	OM3000/10 or OM3000/10 + OG2002
BMW	3 Series (E90/E91/E92/E93)	05 - 03/07	MRS5	OM3000/10
BMW	3 Series (E90/E91/E92/E93)	06 - 03/07	ACSM	OM3000/10

Due to model changes, dates may not be precise. Try other leads or systems before contacting product support.  
 Petrol vehicles MY2000 on (diesel MY2004 on) should be EOBD compliant and can be diagnosed via EOBD for emissions data.

**FASTCHECK AIRBAG**

Make	Model	From/To	System	Harness Required
BMW	3 Series (E90/E91/E92/E93)	03/07 -	MRS5 (CAN)	OM3000/10
BMW	5 Series (E34)	91 - 93	Driver Airbag (5WK4 060)	OM3000/10 + OG2002
BMW	5 series (E34)	93 - 95	1 or 2 airbags (ZAE, BAE)	OM3000/10 + OG2002
BMW	5 Series (E39)	96 - 04	ZAE BAE, ZAE2, MRS 1, MRS 2, MRS 3, MRS 4	OM3000/10 or OM3000/10 + OG2002
BMW	5 Series (E60/E61)	04 - 03/07	ACSM	OM3000/10
BMW	5 Series (E60/E61)	03/07 -	MRS6	OM3000/10
BMW	6 Series (E63/E64)	05 - 03/07	ACSM	OM3000/10
BMW	6 Series (E63/E64)	03/07 -	MRS6	OM3000/10
BMW	7 Series (E32)	91 - 93	Driver Airbag (5WK4 060)	OM3000/10 + OG2002
BMW	7 Series (E38)	94 - 02	ZAE BAE, ZAE2, MRS 1, MRS 2, MRS 3, MRS 4	OM3000/10 or OM3000/10 + OG2002
BMW	7 Series (E65)	02 - 03/07	Multi-bag system	OM3000/10
BMW	8 series (E31)	93 - 95	1 or 2 airbags (ZAE, BAE)	OM3000/10 + OG2002
BMW	8 Series (E31)	90 - 99	ZAE BAE, ZAE2, MRS 1, MRS 2	OM3000/10 + OG2002
BMW	X3 (E83)	03 -	MRS 4 Redesign	OM3000/10
BMW	X5 (E53)	00 -	MRS 3, MRS 4	OM3000/10
BMW	X5 (E70)	06 -	ACSM (CAN)	OM3000/10
BMW	X6 (E71)	08 -	ACSM (CAN)	OM3000/10
BMW	Z3 (E36)	96 - 03	MRS 3, MRS 4	OM3000/10 or OM3000/10 + OG2002
BMW	Z4 (E85/E86)	06 -	ACSM	OM3000/10
BMW	Z8 (E52)	00 - 03	MRS 3, MRS 4	OM3000/10 or OM3000/10 + OG2002
Citroen	Berlingo	96 - 00	Airbag/ Seat Belt	OM3000/10
Citroen	Berlingo	00 -	Autoliv ACU /TRW Airbag	OM3000/10
Citroen	C1	05 -	TRW Airbag	OM3000/10
Citroen	C2	03 -	Autoliv ACU	OM3000/10
Citroen	C2	03 -	SAC Temic CAN	OM3000/10
Citroen	C3	02 -	Temic SRS	OM3000/10
Citroen	C3 II	05 -	SAC Temic CAN	OM3000/10
Citroen	C4	04 -	Temic SRS	OM3000/10
Citroen	C4 / C4 Picasso	03 -	SAC Autoliv CAN	OM3000/10
Citroen	C5	00 -	Temic SRS	OM3000/10
Citroen	C5 II	04 -	SAC Autoliv CAN	OM3000/10
Citroen	C6	05 -	SAC Autoliv CAN	OM3000/10
Citroen	C8	02 -	Temic SRS	OM3000/10
Citroen	C8	06 -	SAC Temic CAN	OM3000/10
Citroen	Dispatch/Jumpy	95 - 00	Airbag / Seat Belt / Side Airbags	OM3000/10
Citroen	Dispatch/Jumpy	00 -	Autoliv ACU	OM3000/10
Citroen	Evasion	95 - 00	Airbag / Seat Belt / Side Airbags	OM3000/10
Citroen	Evasion	00 -	Autoliv ACU	OM3000/10
Citroen	Relay / Jumper	94 - 00	Breed SRS / Breed 97 MY / Siemens 99 MY	Use Fiat Ducato
Citroen	Saxo	96 - 00	Airbag / Seat Belt	OM3000/10
Citroen	Saxo	00 - 03	Autoliv ACU	OM3000/10
Citroen	Synergie	96 - 00	Airbag/ Seat Belt/ Side Airbags	OM3000/10
Citroen	Synergie	00 - 03	Autoliv ACU	OM3000/10
Citroen	Xantia	96 - 00	Airbag/ Seat Belt/ Side Airbags	OM3000/10
Citroen	Xantia	00 - 02	Autoliv ACU	OM3000/10
Citroen	XM	96 - 98	Airbag/ Seat Belt	OM3000/10
Citroen	XM	00 - 01	Autoliv ACU	OM3000/10
Citroen	Xsara	00 -	Autoliv ACU	OM3000/10
Citroen	Xsara Picasso	00 -	Autoliv ACU	OM3000/10

Due to model changes, dates may not be precise. Try other leads or systems before contacting product support.  
 Petrol vehicles MY2000 on (diesel MY2004 on) should be EOBD compliant and can be diagnosed via EOBD for emissions data.

**FASTCHECK AIRBAG**

Make	Model	From/To	System	Harness Required
Fiat	500	07 -	SIEMENS Airbag (EP-Proxi)	OM3000/10
Fiat	Barchetta	96 - 98	TRW2 Airbag w/pretensioners	OM3000/10 or OM3000/10 + OG2023
Fiat	Barchetta	97 - 00	TRW MY97	OM3000/10 or OM3000/10 + OG2023
Fiat	Bravo/Brava	95 - 00	Breed	OM3000/10 or OM3000/10 + OG2023
Fiat	Bravo/Brava	97 - 02	Breed MY97	OM3000/10 or OM3000/10 + OG2023
Fiat	Bravo '07	07 -	TRW MY03	OM3000/10
Fiat	Coupe	94 - 02	TRW2 , TRW MY97	OM3000/10 or OM3000/10 + OG2023
Fiat	Croma '05	05 -	TRW MY03	OM3000/10
Fiat	Doblo	00 - 05	Autoliv MY99	OM3000/10
Fiat	Ducato	94 - 02	Breed Airbag w/pretensioners, Breed MY97, TRW MY99	OM3000/10 or OM3000/10 + OG2023
Fiat	Ducato RST	01 -	Siemens MY99	OM3000/10
Fiat	Idea	04 -	TRW MY03	OM3000/10
Fiat	Marea/Weekend	96 - 02	Allied Signal, Allied MY97, Breed MY97	OM3000/10 or OM3000/10 + OG2023
Fiat	Multipla	98 - 01	Breed 97	OM3000/10 or OM3000/10 + OG2023
Fiat	Multipla	02 -	Siemens MY99	OM3000/10
Fiat	Palio	97 - 01	TRW2, TRW MY97	OM3000/10 or OM3000/10 + OG2023
Fiat	Palio RST	01 - 02	TRW MY97	OM3000/10
Fiat	Palio RST 2	02 -	TRW MY97	OM3000/10
Fiat	Panda '03	03 -	TRW MY99	OM3000/10
Fiat	Punto	93 - 99	TRW2, TRW MY97	OM3000/10 or OM3000/10 + OG2023
Fiat	Punto '99	99 - 03	TRW MY97	OM3000/10 or OM3000/10 + OG2023
Fiat	Punto '03	03 - 05	TRW MY97, TRW MY99	OM3000/10
Fiat	Punto '05 (Grande Punto)	05 -	TRW Airbag (EP-Proxi)	OM3000/10
Fiat	Scudo	96 - 04	Autoliv ACU, Autoliv Central Airbags	OM3000/10
Fiat	Seicento	98 - 04	TRW MY97	OM3000/10 or OM3000/10 + OG2023
Fiat	Stilo	01 - 07	Siemens MY99	OM3000/10
Fiat	Ulysse	95 - 02	Autoliv Central Airbags, Autoliv side airbags	OM3000/10
Fiat	Ulysse '02	02 - 05	Temic SRS	OM3000/10
Ford	Cougar	99 - 02	IABM - Integrated Airbag Module	OM3000/10
Ford	Crown Victoria	96 - 98	IABM - Integrated Airbag Module	OM3000/10
Ford	Crown Victoria	98 - 07	ECS - Electronic Crash Sensor	OM3000/10
Ford	Crown Victoria	00 - 07	RCM - Restraint Control Module	OM3000/10
Ford	Escort	95 - 02	ECS - Electronic Crash Sensor	OM3000/10
Ford	Expedition	97- 99	IABM - Integrated Airbag Module	OM3000/10
Ford	Expedition	99 - 08	RCM - Restraint Control Module	OM3000/10
Ford	Explorer	96 - 06	IABM - Integrated Airbag Module	OM3000/10
Ford	Explorer	00 -	RCM - Restraint Control Module	OM3000/10
Ford	Excursion	00 - 05	ECS - Electronic Crash Sensor	OM3000/10
Ford	Excursion	05 -	RCM - Restraint Control Module	OM3000/10
Ford	E-Series	97 - 05	ECS - Electronic Crash Sensor	OM3000/10
Ford	E-Series	05 - 08	RCM - Restraint Control Module	OM3000/10
Ford	F-250 Light Duty	97 - 99	IABM - Integrated Airbag Module	OM3000/10
Ford	F-250 Light Duty	99 - 02	RCM - Restraint Control Module	OM3000/10
Ford	Fiesta	99 - 07	ECS - Electronic Crash Sensor	OM3000/10
Ford	Fiesta	02 - 07	RCM - Restraint Control Module	OM3000/10
Ford	Fiesta	08 -	RCM - Restraint Control Module	OM3000/10
Ford	Focus I	99 - 04	ECS - Electronic Crash Sensor	OM3000/10
Ford	Focus I	99 - 04	RCM - Restraint Control Module	OM3000/10
Ford	Focus II	04 -	RCM - Restraint Control Module	OM3000/10

Due to model changes, dates may not be precise. Try other leads or systems before contacting product support.  
 Petrol vehicles MY2000 on (diesel MY2004 on) should be EOBD compliant and can be diagnosed via EOBD for emissions data.

**FASTCHECK AIRBAG**

Make	Model	From/To	System	Harness Required
Ford	Focus C-MAX	02 -	ECS - Electronic Crash Sensor	OM3000/10
Ford	Focus C-MAX	02 -	RCM - Restraint Control Module	OM3000/10
Ford	F-Series Super Duty	99 - 02	ECS - Electronic Crash Sensor	OM3000/10
Ford	F-Series Super Duty	01 -	RCM - Restraint Control Module	OM3000/10
Ford	Galaxy	99 - 06	RCM - Restraint Control Module	OM3000/10
Ford	Galaxy	06 -	RCM - Restraint Control Module	OM3000/10
Ford	GT	05 - 06	RCM - Restraint Control Module	OM3000/10
Ford	Fusion	02 - 08	RCM - Restraint Control Module	OM3000/10
Ford	Fusion II	09 -	RCM - Restraint Control Module	OM3000/10
Ford	Ka	96 - 08	ECS - Electronic Crash Sensor	OM3000/10
Ford	Ka II	08 -	Airbag	OM3000/10
Ford	Street Ka	03 - 08	ECS - Electronic Crash Sensor	OM3000/10
Ford	Kuga	08 -	RCM - Restraint Control Module	OM3000/10
Ford	Maverick	01 - 04	RCM - Restraint Control Module	OM3000/10
Ford	Maverick 05	05 -	RCM - Restraint Control Module	OM3000/10
Ford	Mondeo III	01 - 06	RCM - Restraint Control Module	OM3000/10
Ford	Mondeo IV	07 -	RCM - Restraint Control Module	OM3000/10
Ford	Ranger	06 -	RCM - Restraint Control Module	OM3000/10
Ford	S-Max	06 -	RCM - Restraint Control Module	OM3000/10
Ford	Transit	00 - 06	RCM - Restraint Control Module	OM3000/10
Ford	Transit	06 -	RCM - Restraint Control Module	OM3000/10
Ford	Transit / Torneo Connect	02 -	ECS - Electronic Crash Sensor	OM3000/10
Ford	WindStar	96 - 98	IABM - Integrated Airbag Module	OM3000/10
Ford	WindStar	99 - 04	RCM - Restraint Control Module	OM3000/10
GM	Agila-A	00 - 08	Agila SRS	OM3000/10
GM	Astra F	94 - 98	Airbag S	OM3000/10
GM	Astra-G	98 - 04	Airbag SAB6	OM3000/10
GM	Astra-H	04 -	Astra-H SDM Airbag	OM3000/10
GM	Calibra	93 - 97	Airbag S	OM3000/10
GM	Cavalier	93 - 95	Airbag S	OM3000/10
GM	Combo	02 - 06	Airbag 20	OM3000/10
GM	Corsa-B	94 - 01	Airbag S	OM3000/10
GM	Corsa-B	94 - 01	Airbag SAB6	OM3000/10
GM	Corsa-C	01 - 06	Airbag 20	OM3000/10
GM	Corsa-D	06 -	Corsa-D SDM Airbag	OM3000/10
GM	Frontera-A	97 - 98	Airbag SDM (5V)	OM3000/10
GM	Frontera-B	99 - 02	Airbag SDM (5V)	OM3000/10
GM	Meriva-A	03 - 08	Airbag 20	OM3000/10
GM	Monterey	97 - 98	Airbag SDM (5V)	OM3000/10
GM	Movano	04 - 06	Airbag ACU3 (Renault)	OM3000/10
GM	Omega-B	94 - 99	Airbag S	OM3000/10
GM	Omega-B	94 - 01	Airbag SAB6	OM3000/10
GM	Omega-B	01 - 03	Airbag 20	OM3000/10
GM	Signum	01 -	Signum SDM Airbag	OM3000/10
GM	Speedster / VX220	01 - 06	Airbag	OM3000/10
GM	Tigra-A	95 - 99	Airbag S	OM3000/10
GM	Tigra-B	05 - 08	Airbag 20	OM3000/10
GM	Vectra-A	93 - 95	Airbag S	OM3000/10
GM	Vectra-B	95 - 01	Airbag SAB6	OM3000/10

Due to model changes, dates may not be precise. Try other leads or systems before contacting product support.  
 Petrol vehicles MY2000 on (diesel MY2004 on) should be EOBD compliant and can be diagnosed via EOBD for emissions data.

**FASTCHECK AIRBAG**

Make	Model	From/To	System	Harness Required
GM	Vectra-B	95 - 01	Airbag SAE4	OM3000/10
GM	Vectra-B	95 - 01	Airbag	OM3000/10
GM	Vectra-C	01 -	Vectra-C SDM Airbag	OM3000/10
GM	Vivaro	01 - 06	Airbag ACU3 (Renault)	OM3000/10
GM	Zafira-A	99 - 05	Airbag SAB6	OM3000/10
GM	Zafira-B	05 -	Zafira-B SDM Airbag	OM3000/10
Lancia	Kappa	94 - 01	TRW2 Airbag w/pretensioners, TRW MY97	OM3000/10 or OM3000/10 + OG2023
Lancia	Lybra	99 - 06	Allied MY97, Siemens MY99	OM3000/10 or OM3000/10 + OG2023
Lancia	Musa	04 - 06	TRW MY03	OM3000/10
Lancia	Phedra	02 - 06	Temic SRS	OM3000/10
Lancia	Thesis	02 - 06	TRW MY99	OM3000/10
Lancia	Y	96 - 03	Allied Signal, Allied MY97	OM3000/10 or OM3000/10 + OG2023
Lancia	Ypsilon	03 - 06	Autoliv MY99	OM3000/10
Lancia	Z	96 - 02	Autoliv, Autoliv ACU	OM3000/10
Land Rover	Freelander	98 - 02	Autoliv AC4	OM3000/10
Land Rover	Freelander	03 - 06	Siemens SRE Smart	OM3000/10
Land Rover	Freelander II (L359)	07 -	RCM - Restraint Control Module	OM3000/10
Land Rover	Discovery	96 - 98	TRW SPS	OM3000/10
Land Rover	Discovery II	98 - 04	TRW Generation 4	OM3000/10
Land Rover	Discovery III (L319)	05 -	RCM - Restraint Control Module	OM3000/10
Land Rover	Range Rover (P38a)	97 - 02	TRW SPS	OM3000/10
Land Rover	Range Rover (L322)	03 -	Bosch MRS4	OM3000/10
Land Rover	Range Rover Sport (L320)	05 -	RCM - Restraint Control Module	OM3000/10
Lexus	GS II	97 - 04	SRS KW2 9600	OM3000/10
Lexus	GS III	05 -	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Lexus	IS	98 - 05	SRS KW2 9600	OM3000/10
Lexus	IS II	06 -	SRS KW2 10400	OM3000/10
Lexus	LS III	01 - 06	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Lexus	LS IV	06 -	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Lexus	RX	98 - 03	SRS KW2 9600	OM3000/10
Lexus	RX II	04 - 09	SRS KW2 9600	OM3000/10
Lexus	SC II	01 -	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Mercedes	A Class (W168)	98 - 03	Fast Codes	OM3000/10
Mercedes	A Class (W169)	04 -	AB 169	OM3000/10
Mercedes	B Class (W245)	05 -	AB 169	OM3000/10
Mercedes	C Class (W202)	93 - 01	Fast Codes	OM3000/10
Mercedes	C Class (W203)	00 - 09/03	Arminca	OM3000/10
Mercedes	C Class (W203)	09/03 - 07	Armada	OM3000/10
Mercedes	C Class (W203)	09/03 - 07	WSS	OM3000/10
Mercedes	CL Class (W215)	99 - 09/02	Armin	OM3000/10
Mercedes	CL Class (W215)	09/02 - 06	Armada 2	OM3000/10
Mercedes	CLK (W208)	93 - 03	Fast Codes	OM3000/10
Mercedes	CLK (W209)	02 - 04/04	Arminca	OM3000/10
Mercedes	CLK (W209)	04/04 - 02	Armada	OM3000/10
Mercedes	CLK (W209)	04/04 - 02	WSS	OM3000/10
Mercedes	CLS (W219)	04 -	Armada	OM3000/10
Mercedes	CLS (W219)	04 -	RGSL 211	OM3000/10
Mercedes	CLS (W219)	04 -	RGSR 211	OM3000/10
Mercedes	CLS (W219)	04 -	WSS	OM3000/10

Due to model changes, dates may not be precise. Try other leads or systems before contacting product support.  
 Petrol vehicles MY2000 on (diesel MY2004 on) should be EOBD compliant and can be diagnosed via EOBD for emissions data.

**FASTCHECK AIRBAG**

Make	Model	From/To	System	Harness Required
Mercedes	E Class (W210)	95 - 03	Fast Codes	OM3000/10
Mercedes	E Class (W211)	02 -	Armada	OM3000/10
Mercedes	E Class (W211)	02 -	RGSL 211	OM3000/10
Mercedes	E Class (W211)	02 -	RGSR 211	OM3000/10
Mercedes	E Class (W211)	02 -	WSS	OM3000/10
Mercedes	G Class (W461)	98 - 02	Fast Codes	OM3000/10
Mercedes	G Class (W463)	98 -	Fast Codes	OM3000/10
Mercedes	G Class (W463)	98 -	Armin	OM3000/10
Mercedes	M Class (W163)	93 - 03	Fast Codes	OM3000/10
Mercedes	M Class (W164)	05 -	Arcade 164	OM3000/10
Mercedes	M Class (W164)	05 -	RGSL 164	OM3000/10
Mercedes	M Class (W164)	05 -	RGSR 164	OM3000/10
Mercedes	M Class (W164)	05 -	WSS	OM3000/10
Mercedes	R Class (251)	05 -	Arcade 164	OM3000/10
Mercedes	R Class (251)	05 -	RGSL 164	OM3000/10
Mercedes	R Class (251)	05 -	RGSR 164	OM3000/10
Mercedes	R Class (251)	05 -	WSS	OM3000/10
Mercedes	S Class (W140)	91 - 08	Fast Codes	OM3000/10
Mercedes	S Class (W220)	98 - 09/02	Fast Codes	OM3000/10
Mercedes	S Class (W220)	09/02 -	Armada 2	OM3000/10
Mercedes	S Class (W220)	09/02 -	REVASL	OM3000/10
Mercedes	S Class (W220)	09/02 -	REVASR	OM3000/10
Mercedes	S Class (W221)	05 -	Arcade 221	OM3000/10
Mercedes	S Class (W221)	05 -	RGSL 221	OM3000/10
Mercedes	S Class (W221)	05 -	RGSR 221	OM3000/10
Mercedes	S Class (W221)	05 -	WSS 221	OM3000/10
Mercedes	SL (R129)	93 - 03	Fast Codes	OM3000/10
Mercedes	SL (R230)	03 - 06	Armada 2	OM3000/10
Mercedes	SLK (R170)	93 - 03	Fast Codes	OM3000/10
Mercedes	SLK (R171)	04 -	Armada	OM3000/10
Mercedes	SLR (199)	04 -	Armada 2	OM3000/10
Mercedes	Sprinter (W901 / W902 / W903 / W904)	95 - 02	Fast Codes	OM3000/10 or OM3000/10 + OG2009
Mercedes	Vaneo (414)	02 -	Armin	OM3000/10
Mercedes	Viano (639)	03 -	Armada	OM3000/10
Mercedes	Vito (639)	03 -	Armada	OM3000/10
MINI	MINI (R50 / R53)	00 - 07	MRS 4	OM3000/10
MINI	MINI (R55 / R56 / R57)	06 -	MRS 6	OM3000/10
Peugeot	107	05 -	TRW Airbag	OM3000/10
Peugeot	1007	04 - 06	TRW Airbag	OM3000/10
Peugeot	1007	04 -	SAC Gonflable CAN	OM3000/10
Peugeot	106	96 - 00	Airbag / Seat Belt	OM3000/10
Peugeot	106	00 - 04	Autoliv ACU	OM3000/10
Peugeot	206	98 - 00	Airbag / Seat Belt / Side Airbags	OM3000/10
Peugeot	206	00 - 06	Autoliv ACU / Temic SRS	OM3000/10
Peugeot	207	06 -	SAC Gonflable CAN	OM3000/10
Peugeot	306	96 - 00	Airbag / Seat Belt / Side Airbags	OM3000/10
Peugeot	306	00 - 02	Autoliv ACU	OM3000/10
Peugeot	307	01 - 07	Temic SRS	OM3000/10
Peugeot	307 II	04 -	SAC Gonflable CAN	OM3000/10

Due to model changes, dates may not be precise. Try other leads or systems before contacting product support.  
 Petrol vehicles MY2000 on (diesel MY2004 on) should be EOBD compliant and can be diagnosed via EOBD for emissions data.

**FASTCHECK AIRBAG**

Make	Model	From/To	System	Harness Required
Peugeot	308	07 -	SAC Gonflable CAN	OM3000/10
Peugeot	406	95 - 00	Airbag/ Seat Belt/ Side Airbags	OM3000/10
Peugeot	406	00 - 03	Autoliv ACU	OM3000/10
Peugeot	407	05 -	Temic SRS	OM3000/10
Peugeot	407	05 -	SAC Gonflable CAN	OM3000/10
Peugeot	605	97 - 00	Airbag/ Seat Belt/ Side Airbags	OM3000/10
Peugeot	607	01 - 06	Temic SRS	OM3000/10
Peugeot	806	96 - 00	Airbag/ Seat Belt/ Side Airbags	OM3000/10
Peugeot	806	00 - 03	Autoliv ACU	OM3000/10
Peugeot	807	02 -	Temic SRS	OM3000/10
Peugeot	807	05 -	SAC Gonflable CAN	OM3000/10
Peugeot	Boxer	96 - 00	Breed SRS / Breed 97 MY / Siemens 99 MY	Use Fiat Ducato
Peugeot	Expert	97 - 00	Airbag/ Seat Belt	OM3000/10
Peugeot	Expert	00 -	Autoliv ACU	OM3000/10
Peugeot	Partner/Ranch	96 - 00	Airbag/ Seat Belt	OM3000/10
Peugeot	Partner/Ranch	00 -	Autoliv ACU / TRW Airbag	OM3000/10
Renault	Avantime	01 - 03	Siemens Autoliv ACU3	OM3000/10
Renault	Clio II	98 - 06	AB7	OM3000/10
Renault	Clio II	98 - 06	AB8	OM3000/10
Renault	Clio III	06 -	AB9	OM3000/10
Renault	Clio III	06 -	Airbag	OM3000/10
Renault	Espace IV	02 -	Siemens Autoliv ACU3	OM3000/10
Renault	Espace IV	02 -	Siemens Autoliv ACU4	OM3000/10
Renault	Kangoo	97 - 02	Siemens Autoliv ACU 3.8	OM3000/10
Renault	Kangoo	97 - 02	AC4	OM3000/10
Renault	Kangoo	97 - 02	AC4 Phase 2	OM3000/10
Renault	Kangoo	97 - 02	AC6	OM3000/10
Renault	Kangoo	97 - 02	AC6 Phase 2	OM3000/10
Renault	Kangoo	97 - 02	EC5	OM3000/10
Renault	Kangoo II	02 - 08	Siemens Autoliv ACU 3.8	OM3000/10
Renault	Kangoo II	02 - 08	AC4	OM3000/10
Renault	Kangoo II	02 - 08	AC4 Phase 2	OM3000/10
Renault	Kangoo II	02 - 08	AC6	OM3000/10
Renault	Kangoo II	02 - 08	AC6 Phase 2	OM3000/10
Renault	Kangoo III	08 -	AB9	OM3000/10
Renault	Laguna	93 - 00	AC4	OM3000/10
Renault	Laguna	93 - 00	AC4 Phase 2	OM3000/10
Renault	Laguna	93 - 00	AC6	OM3000/10
Renault	Laguna	93 - 00	AC6 Phase 2	OM3000/10
Renault	Laguna	93 - 00	EC5	OM3000/10
Renault	Laguna II	01 - 07	Siemens Autoliv ACU3	OM3000/10
Renault	Laguna II	01 - 07	Siemens Autoliv ACU3.8	OM3000/10
Renault	Laguna II	01 - 07	Siemens Autoliv ACU4	OM3000/10
Renault	Master	95 -	AC4	OM3000/10
Renault	Master	95 -	AC4 Phase 2	OM3000/10
Renault	Master	95 -	AC6	OM3000/10
Renault	Master	95 -	AC6 Phase 2	OM3000/10
Renault	Master	95 -	EC5	OM3000/10
Renault	Megane	95 - 02	AC4	OM3000/10

Due to model changes, dates may not be precise. Try other leads or systems before contacting product support.  
 Petrol vehicles MY2000 on (diesel MY2004 on) should be EOBD compliant and can be diagnosed via EOBD for emissions data.

**FASTCHECK AIRBAG**

<b>Make</b>	<b>Model</b>	<b>From/To</b>	<b>System</b>	<b>Harness Required</b>
Renault	Megane	95 - 02	AC4 Phase 2	OM3000/10
Renault	Megane	95 - 02	AC6	OM3000/10
Renault	Megane	95 - 02	AC6 Phase 2	OM3000/10
Renault	Megane	95 - 02	ACU 3.8	OM3000/10
Renault	Megane	95 - 02	EC5	OM3000/10
Renault	Megane II	02 -	Siemens Autoliv ACU4 MK2	OM3000/10
Renault	Megane II	02 -	Siemens Autoliv ACU4	OM3000/10
Renault	Modus	04 -	AB9	OM3000/10
Renault	Modus	04 -	Airbag	OM3000/10
Renault	Scenic	95 - 02	AC4	OM3000/10
Renault	Scenic	95 - 02	AC4 Phase 2	OM3000/10
Renault	Scenic	95 - 02	AC6	OM3000/10
Renault	Scenic	95 - 02	AC6 Phase 2	OM3000/10
Renault	Scenic	95 - 02	EC5	OM3000/10
Renault	Scenic II	03 -	Siemens Autoliv ACU4 MK2	OM3000/10
Renault	Scenic II	03 -	Siemens Autoliv ACU3.8	OM3000/10
Renault	Scenic II	03 -	Siemens Autoliv ACU4	OM3000/10
Renault	Trafic	97 - 00	AC4	OM3000/10
Renault	Trafic	97 - 00	AC4 Phase 2	OM3000/10
Renault	Trafic	97 - 00	EC5	OM3000/10
Renault	Trafic II	01 -	Siemens Autoliv ACU3	OM3000/10
Renault	Twingo	92 - 07	AC4	OM3000/10
Renault	Twingo	92 - 07	AC4 Phase 2	OM3000/10
Renault	Twingo	92 - 07	AC6	OM3000/10
Renault	Twingo	92 - 07	AC6 Phase 2	OM3000/10
Renault	Twingo	92 - 07	EC5	OM3000/10
Renault	Vel Satis	01 -	Siemens Autoliv ACU3	OM3000/10
Seat	Alhambra	96 -	KWP1281 / KW2000	OM3000/10
Seat	Altea	04 -	CAN	OM3000/10
Seat	Arosa	97 - 05	KWP1281 / KW2000	OM3000/10
Seat	Cordoba	93 -	KWP1281 / KW2000	OM3000/10
Seat	Ibiza	93 -	KWP1281 / KW2000	OM3000/10
Seat	Leon	00 - 04	KWP1281 / KW2000	OM3000/10
Seat	Leon	04 -	CAN	OM3000/10
Seat	Toledo	92 - 05	KWP1281 / KW2000	OM3000/10
Seat	Toledo III	04 -	CAN	OM3000/10
Skoda	Fabia	00 - 07	KWP1281 / KW2000	OM3000/10
Skoda	Fabia II	07 -	CAN	OM3000/10
Skoda	Felicia	95 - 04	KWP1281 / KW2000	OM3000/10
Skoda	Octavia	96 - 04	KWP1281 / KW2000	OM3000/10
Skoda	Octavia II	04 -	CAN	OM3000/10
Skoda	Superb	02 - 04	KWP1281 / KW2000	OM3000/10
Toyota	Auris	07 -	SRS KW2 10400	OM3000/10
Toyota	Avensis	98 - 03	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Avensis II	03 - 08	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Avensis Verso	01 -	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Aygo	05 -	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Camry (XV20)	96 - 01	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Camry (XV30)	01 - 06	SRS KW2 9600 / SRS KW2 10400	OM3000/10

Due to model changes, dates may not be precise. Try other leads or systems before contacting product support.  
 Petrol vehicles MY2000 on (diesel MY2004 on) should be EOBD compliant and can be diagnosed via EOBD for emissions data.

**FASTCHECK AIRBAG**

Make	Model	From/To	System	Harness Required
Toyota	Celica VII	99 - 06	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Corolla VIII (E110)	97 - 02	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Corolla IX (E120)	02 -	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Corolla Verso	04 -	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Hiace IV	98 - 06	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Hilux	97 -	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Land Cruiser (J90)	96 - 98	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Land Cruiser (J100)	98 - 03	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Land Cruiser (J120)	03 -	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	MR2 III (ZZW30)	00 - 06	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Picnic I	96 - 02	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Previa I	97 - 00	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Previa II	00 - 06	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Prius (NHW20)	04 - 09	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	RAV4 I (XA1)	97 - 00	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	RAV4 II (CA20W)	00 - 06	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	RAV4 III (CA30W)	06 -	SRS KW2 10400	OM3000/10
Toyota	Yaris I	99 - 06	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Toyota	Yaris II	06 -	SRS KW2 10400	OM3000/10
Toyota	Yaris Verso	99 - 06	SRS KW2 9600 / SRS KW2 10400	OM3000/10
Volvo	S40	04 - 06	P1X	OM3000/10
Volvo	V50	03 - 08	P1X	OM3000/10
Volvo	S60	01 - 05	P2X	OM3000/10
Volvo	V70	00 - 07	P2X	OM3000/10
Volvo	XC70	00 - 06	P2X	OM3000/10
Volvo	S80	99 - 06	P2X	OM3000/10
Volvo	XC90	02 - 06	P2X	OM3000/10
VW	Beetle	99 -	KWP1281 / KW2000	OM3000/10
VW	Bora	98 - 05	KWP1281 / KW2000	OM3000/10 or OM3000/10 + OG2022
VW	Bora	05 -	CAN	OM3000/10
VW	Cabrio	95 - 02	KWP1281 / KW2000	OM3000/10 or OM3000/10 + OG2022
VW	Caddy	92 - 05	KWP1281 / KW2000	OM3000/10 or OM3000/10 + OG2022
VW	Caddy	05 -	CAN	OM3000/10
VW	Corrado	91 - 95	KWP1281 / KW2000	OM3000/10 or OM3000/10 + OG2022
VW	EOS	05 -	CAN	OM3000/10
VW	Eurovan	99 - 03	KWP1281 / KW2000	OM3000/10 or OM3000/10 + OG2022
VW	Golf/GTI	91 - 03	KWP1281 / KW2000	OM3000/10 or OM3000/10 + OG2022
VW	Golf/GTI	03 -	CAN	OM3000/10
VW	Golf Plus	05 -	CAN	OM3000/10
VW	Jetta	93 - 04	KWP1281 / KW2000	OM3000/10 or OM3000/10 + OG2022
VW	Jetta	05 -	CAN	OM3000/10
VW	Lupo	98 - 05	KWP1281 / KW2000	OM3000/10 or OM3000/10 + OG2022
VW	Passat	94 - 05	KWP1281 / KW2000	OM3000/10 or OM3000/10 + OG2022
VW	Passat	05 -	CAN	OM3000/10
VW	Phaeton	03 -	PhWP1281 / KW2000	OM3000/10
VW	Polo	98 -	KWP1281 / KW2000	OM3000/10 or OM3000/10 + OG2022
VW	Touareg	03 - 06	KWP1281 / KW2000	OM3000/10
VW	Touareg	07 -	CAN	OM3000/10
VW	Touran	03 -	CAN	OM3000/10

Due to model changes, dates may not be precise. Try other leads or systems before contacting product support.  
 Petrol vehicles MY2000 on (diesel MY2004 on) should be EOBD compliant and can be diagnosed via EOBD for emissions data.

**FASTCHECK AIRBAG**

<b>Make</b>	<b>Model</b>	<b>From/To</b>	<b>System</b>	<b>Harness Required</b>
VW	Sharan	95 -	KWP1281 / KW2000	OM3000/10 or OM3000/10 + OG2022
VW	Transporter/Caravelle	92 - 04	KWP1281 / KW2000	OM3000/10 or OM3000/10 + OG2022
VW	Transporter/Caravelle T5	04 -	CAN	OM3000/10
VW	Vento	92 - 98	KWP1281 / KW2000	OM3000/10 or OM3000/10 + OG2022