



## OmiNspect

### Vehicle Application List - Version 4.0.0

This document should be used in conjunction with Operating Instructions.  
The Operating Instructions will assist you in locating the correct vehicle connector and identifying the required interface cable.

Make	Model	From/To	System	Harness Required
Alfa Romeo	145	94 - 98	TRW2	OM98/16 or OM97/15 D1
Alfa Romeo	145	94 - 00	TRW MY97	OM98/16 or OM97/15 D1
Alfa Romeo	146	94 - 98	TRW2	OM98/16 or OM97/15 D1
Alfa Romeo	146	95 - 00	TRW MY97	OM98/16 or OM97/15 D1
Alfa Romeo	147	00 - 04	Allied MY97	OM97/15 D1
Alfa Romeo	147	00 - 07	Siemens MY99	OM97/15 D1
Alfa Romeo	156	97 - 02	Allied MY97, Allied Signal, Allied Signal 2	OM98/16 or OM97/15 D1
Alfa Romeo	156 '02	02 - 05	Siemens MY99	OM97/15 D1
Alfa Romeo	159	05 -	TRW MY03	OM98/10 or OM98/17
Alfa Romeo	166	98 - 03	TRW MY97, TRW MY99	OM98/16 or OM97/15 D1
Alfa Romeo	GT	04 -	Siemens MY99	OM97/15 D1
Alfa Romeo	GTV	95 - 98	TRW2 Airbag w/pretensioners	OM98/16 or OM97/15 D1
Alfa Romeo	GTV	97 - 03	TRW MY97	OM98/16 or OM97/15 D1
Alfa Romeo	Spider	95 - 98	TRW2 Airbag w/pretensioners	OM98/16 or OM97/15 D1
Alfa Romeo	Spider	97 - 03	TRW MY97	OM98/16 or OM97/15 D1
Audi	80/Cabrio/Coupe/Quattro	94 - 96	KWP1281	OM97/17
Audi	A2	00 - 04	KWP1281/KW2000	OM97/15 A1
Audi	A3	96 - 04	KWP1281/KW2000	OM97/15 A1
Audi	A3	04 -	CAN	OM98/10
Audi	A4	95 - 04	KWP1281/KW2000	OM97/15 A1
Audi	A4	04 -	CAN	OM98/10
Audi	S4	95 - 04	KWP1281/KW2000	OM97/17
Audi	S4	04 -	CAN	OM98/10
Audi	A6	97 - 04	KWP1281/KW2000	OM97/15 A1
Audi	A6	04 -	CAN	OM98/10
Audi	S6	97 - 04	KWP1281/KW2000	OM97/15 A1
Audi	S6	04 -	CAN	OM98/10
Audi	Allroad Quattro	01 - 04	KWP1281/KW2000	OM97/15 A1
Audi	Q7	06 -	CAN	OM98/10
Audi	A8	94 - 04	KWP1281/KW2000	OM97/15 A1
Audi	A8	04 -	CAN	OM98/10
Audi	S8	94 - 04	KWP1281/KW2000	OM97/15 A1
Audi	S8	04 -	CAN	OM98/10
Audi	TT	98 - 07	KWP1281/KW2000	OM97/15 A1
Audi	TT	07 -	CAN	OM98/10
Audi	100	94 - 97	KWP1281/KW2000	OM97/17
BMW	1 Series (E81/E87)	04 - 03/07	MRS5	OM98/18
BMW	3 Series (E30)	91 - 93	Driver Airbag (5WK4 060)	OM97/11
BMW	3 Series (E36)	90 - 98	ZAE BAE, ZAE2, MRS 1, MRS 2, MRS 3	OM97/11 or OM97/15 A6 / OM98/18
BMW	3 Series (E36)	91 - 93	Driver Airbag (5WK4 060)	OM97/11
BMW	3 Series (E36)	93 - 95	1 or 2 airbags (ZAE, BAE)	OM97/11
BMW	3 Series (E46)	98 - 05	MRS 3, MRS 4	OM97/11 or OM97/15 A6 / OM98/18
BMW	3 Series (E90/E91/E92/E93)	05 - 03/07	MRS5	OM98/18
BMW	5 Series (E34)	91 - 93	Driver Airbag (5WK4 060)	OM97/11
BMW	5 series (E34)	93 - 95	1 or 2 airbags (ZAE, BAE)	OM97/11
BMW	5 Series (E39)	96 - 04	ZAE BAE, ZAE2, MRS 1, MRS 2, MRS 3, MRS 4	OM97/11 or OM97/15 A6 / OM98/18

Make	Model	From/To	System	Harness Required
BMW	5 Series (E60/E61)	04 - 03/07	ASCM	OM98/18
BMW	6 Series (E63/E64)	05 - 03/07	ACSM	OM98/18
BMW	7 Series (E32)	91 - 93	Driver Airbag (5WK4 060)	OM97/11
BMW	7 Series (E38)	94 - 02	ZAE BAE, ZAE2, MRS 1, MRS 2, MRS 3, MRS 4	OM97/11 or OM97/15 A6 / OM98/18
BMW	8 series (E31)	93 - 95	1 or 2 airbags (ZAE, BAE)	OM97/11
BMW	8 Series (E31)	90 - 99	ZAE BAE, ZAE2, MRS 1, MRS 2	OM97/11
BMW	X3 (E83)	03 -	MRS 4 Redesign	OM97/15 A6 / OM98/18
BMW	X5 (E53)	00 -	MRS 3, MRS 4	OM97/15 A6 / OM98/18
BMW	Z3 (E36)	96 - 03	MRS 3, MRS 4	OM97/11 or OM97/15 A6 / OM98/18
BMW	Z4 (E85/E86)	06 -	ASCM	OM97/15 A6 / OM98/18
BMW	Z8 (E52)	00 - 03	MRS 3, MRS 4	OM97/11 or OM97/15 A6
Citroen	Berlingo	96 - 00	Airbag/ Seat Belt	OM97/20 or OM97/15 K2 or K9
Citroen	Berlingo	00 -	Autoliv ACU /TRW Airbag	OM97/15 K2 or K9
Citroen	C2	03 -	Autoliv ACU	OM97/15 K2 or K9
Citroen	C3	02 -	Temic SRS	OM97/15 K2 or K9
Citroen	C4	04 -	Temic SRS	OM97/15 K2 or K9
Citroen	C5	00 -	Temic SRS	OM97/15 K2 or K9
Citroen	C8	02 -	Temic SRS	OM97/15 K2 or K9
Citroen	Dispatch/Jumpy	95 - 00	Airbag / Seat Belt / Side Airbags	OM97/20 or OM97/15 K2 or K9
Citroen	Dispatch/Jumpy	00 -	Autoliv ACU	OM97/15 K2 or K9
Citroen	Evasion	95 - 00	Airbag / Seat Belt / Side Airbags	OM97/20 or OM97/15 K2 or K9
Citroen	Evasion	00 -	Autoliv ACU	OM97/15 K2 or K9
Citroen	Relay / Jumper	94 - 00	Breed SRS / Breed 97 MY / Siemens 99 MY	Use Fiat Ducato
Citroen	Saxo	96 - 00	Airbag / Seat Belt	OM97/20 or OM97/15 K2 or K9
Citroen	Saxo	00 - 03	Autoliv ACU	OM97/15 K2 or K9
Citroen	Synergie	96 - 00	Airbag/ Seat Belt/ Side Airbags	OM97/20 or OM97/15 K2 or K9
Citroen	Synergie	00 - 03	Autoliv ACU	OM97/15 K2 or K9
Citroen	Xantia	96 - 00	Airbag/ Seat Belt/ Side Airbags	OM97/20 or OM97/15 K2 or K9
Citroen	Xantia	00 - 02	Autoliv ACU	OM97/15 K2 or K9
Citroen	XM	96 - 98	Airbag/ Seat Belt	OM97/20 or OM97/15 K2 or K9
Citroen	XM	00 - 01	Autoliv ACU	OM97/15 K2 or K9
Citroen	Xsara	00 -	Autoliv ACU	OM97/15 K2 or K9
Citroen	Xsara Picasso	00 -	Autoliv ACU	OM97/15 K2 or K9
Fiat	Barchetta	96 - 98	TRW2 Airbag w/pretensioners	OM98/16 or OM97/15 D1
Fiat	Barchetta	97 - 00	TRW MY97	OM98/16 or OM97/15 D1
Fiat	Bravo/Brava	95 - 00	Breed	OM98/16 or OM97/15 D1
Fiat	Bravo/Brava	97 - 02	Breed MY97	OM98/16 or OM97/15 D1
Fiat	Coupe	94 - 02	TRW2 , TRW MY97	OM98/16 or OM97/15 D1
Fiat	Croma '05	05 -	TRW MY03	OM98/10 or OM98/17
Fiat	Doblo	00 - 05	Autoliv MY99	OM97/15 D1
Fiat	Ducato	94 - 02	Breed Airbag w/pretensioners, Breed MY97, TRW MY99	OM98/16 or OM97/15 D1
Fiat	Ducato RST	01 -	Siemens MY99	OM97/15 D1
Fiat	Idea	04 -	TRW MY03	OM98/17
Fiat	Marea/Weekend	96 - 02	Allied Signal, Allied MY97, Breed MY97	OM98/16 or OM97/15 D1
Fiat	Multipla	98 - 01	Breed 97	OM98/16 or OM97/15 D1
Fiat	Multipla	02 -	Siemens MY99	OM97/15 D1

Make	Model	From/To	System	Harness Required	
Fiat	Palio	97 - 01	TRW2, TRW MY97	OM98/16 or OM97/15 D1	
Fiat	Palio RST	01 - 02	TRW MY97	OM97/15 D1	
Fiat	Palio RST 2	02 -	TRW MY97	OM97/15 D1	
Fiat	Panda 03	03 -	TRW MY99	OM97/15 D1	
Fiat	Punto	93 - 99	TRW2, TRW MY97	OM98/16 or OM97/15 D1	
Fiat	Punto '99	99 - 03	TRW MY97	OM98/16 or OM97/15 D1	
Fiat	Punto '03	03 - 05	TRW MY97, TRW MY99	OM97/15 D1	
Fiat	Scudo	96 - 04	Autoliv ACU, Autoliv Central Airbags	OM97/20 or OM97/15 K2 or K9	
Fiat	Seicento	98 - 04	TRW MY97	OM98/16 or OM97/15 D1	
Fiat	Stilo	01 - 05	Siemens MY99	OM97/15 D1	
Fiat	Ulysse	95 - 02	Autoliv Central Airbags, Autoliv side airbags	OM97/20 or OM97/15 K2 or K9	
Fiat	Ulysse '02	02 - 05	Temic SRS	OM97/20 or OM97/15 K2 or K9	
Ford	Cougar	99 - 02	IABM - Integrated Airbag Module	OM98/10 or OM98/18	
New	Ford	Crown Victoria	96 - 98	IABM - Integrated Airbag Module	OM98/10 or OM98/18
New	Ford	Crown Victoria	98 - 07	ECS - Electronic Crash Sensor	OM98/10 or OM98/18
New	Ford	Crown Victoria	00 - 07	RCM - Restraint Control Module	OM98/10 or OM98/18
Ford	Escort	95 - 02	ECS - Electronic Crash Sensor	OM98/10 or OM98/18	
New	Ford	Expedition	97 - 99	IABM - Integrated Airbag Module	OM98/10 or OM98/18
New	Ford	Expedition	99 - 08	RCM - Restraint Control Module	OM98/10 or OM98/18
Ford	Explorer	96 - 06	IABM - Integrated Airbag Module	OM98/10 or OM98/18	
New	Ford	Explorer	00 -	RCM - Restraint Control Module	OM98/10 or OM98/18
New	Ford	Excursion	00 - 05	ECS - Electronic Crash Sensor	OM98/10 or OM98/18
New	Ford	Excursion	05 -	RCM - Restraint Control Module	OM98/10 or OM98/18
New	Ford	E-Series	97 - 05	ECS - Electronic Crash Sensor	OM98/10 or OM98/18
New	Ford	E-Series	05 - 08	RCM - Restraint Control Module	OM98/10 or OM98/18
New	Ford	F-250 Light Duty	97 - 99	IABM - Integrated Airbag Module	OM98/10 or OM98/18
New	Ford	F-250 Light Duty	99 - 02	RCM - Restraint Control Module	OM98/10 or OM98/18
Ford	Fiesta	99 -	ECS - Electronic Crash Sensor	OM98/10 or OM98/18	
Ford	Fiesta	02 -	RCM - Restraint Control Module	OM98/10 or OM98/18	
Ford	Focus	99 -	ECS - Electronic Crash Sensor	OM98/10 or OM98/18	
Ford	Focus	99 -	RCM - Restraint Control Module	OM98/10 or OM98/18	
New	Ford	Focus C-MAX	05 -	ECS - Electronic Crash Sensor	OM98/10 or OM98/18
New	Ford	Focus C-MAX	05 -	RCM - Restraint Control Module	OM98/10 or OM98/18
New	Ford	F-Series Super Duty	99 - 02	ECS - Electronic Crash Sensor	OM98/10 or OM98/18
New	Ford	F-Series Super Duty	01 -	RCM - Restraint Control Module	OM98/10 or OM98/18
Ford	GT	05 - 06	RCM - Restraint Control Module	OM98/10 or OM98/18	
Ford	Fusion	02 -	RCM - Restraint Control Module	OM98/10 or OM98/18	
Ford	Ka	96 - 06	ECS - Electronic Crash Sensor	OM98/10 or OM98/18	
Ford	Street Ka	03 -	ECS - Electronic Crash Sensor	OM98/10 or OM98/18	
Ford	Maverick	01 - 04	RCM - Restraint Control Module	OM98/10 or OM98/18	
Ford	Maverick 05	05 -	RCM - Restraint Control Module	OM98/10 or OM98/18	
Ford	Mondeo III	01 - 06	RCM - Restraint Control Module	OM98/10 or OM98/18	
Ford	Ranger	06 -	RCM - Restraint Control Module	OM98/10 or OM98/18	
Ford	Transit	00 - 06	RCM - Restraint Control Module	OM98/10 or OM98/18	
Ford	Transit / Torneo Connect	02 -	ECS - Electronic Crash Sensor	OM98/10 or OM98/18	
New	Ford	WindStar	96 - 98	IABM - Integrated Airbag Module	OM98/10 or OM98/18

New

New

New

New

New

New

Make	Model	From/To	System	Harness Required
Ford	WindStar	99 - 04	RCM - Restraint Control Module	OM98/10 or OM98/18
GM	Agila	00 - 08	Agila SRS	OM97/15 A2
GM	Astra F	94 - 98	Airbag S	OM97/15 J7
GM	Astra-G	98 - 04	Airbag SAB6	OM97/15 J7
GM	Astra-H	04 -	Astra-H SDM Airbag	OM98/18
GM	Calibra	93 - 97	Airbag S	OM97/15 J7
GM	Cavalier	93 - 95	Airbag S	OM97/15 J7
GM	Combo	02 - 06	Airbag 20	OM97/15 F2
GM	Corsa-B	94 - 01	Airbag S	OM97/15 J7
GM	Corsa-B	94 - 01	Airbag SAB6	OM97/15 J7
GM	Corsa-C	01 - 06	Airbag 20	OM97/15 F2
GM	Corsa-D	06 -	Corsa-D SDM Airbag	OM98/18
GM	Frontera-A	97 - 98	Airbag SDM (5V)	OM97/15 G2
GM	Frontera-B	99 - 02	Airbag SDM (5V)	OM97/15 G2
GM	Meriva	03 - 08	Airbag 20	OM97/15 F2
GM	Monterey	97 - 98	Airbag SDM (5V)	OM97/15 G2
GM	Omega-B	94 - 99	Airbag S	OM97/15 J7
GM	Omega-B	94 - 01	Airbag SAB6	OM97/15 J7
GM	Omega-B	01 - 03	Airbag 20	OM97/15 F2
GM	Signum	01 -	Signum SDM Airbag	OM98/18
GM	Speedster / VX220	01 - 06	Airbag	OM97/15 J7
GM	Tigra-A	95 - 99	Airbag S	OM97/15 J7
GM	Tigra-B	05 - 08	Airbag 20	OM97/15 F2
GM	Vectra-A	93 - 95	Airbag S	OM97/15 J7
GM	Vectra-B	95 - 01	Airbag SAB6	OM97/15 J7
GM	Vectra-B	95 - 01	Airbag SAE4	OM97/15 J7
GM	Vectra-B	95 - 01	Airbag	OM97/15 J7
GM	Vectra-C	01 -	Vectra-C SDM Airbag	OM98/18
GM	Vivaro	01 - 06	Airbag ACU3	OM97/15 A2
GM	Zafira-A	99 - 05	Airbag SAB6	OM97/15 J7
GM	Zafira-B	05 -	Zafira-B SDM Airbag	OM98/18
Lancia	Kappa	94 - 01	TRW2 Airbag w/pretensioners, TRW MY97	OM98/16 or OM97/15 D1
Lancia	Lybra	99 - 06	Allied MY97, Siemens MY99	OM98/16 or OM97/15 D1
Lancia	Musa	04 - 06	TRW MY03	OM98/17
Lancia	Phedra	02 - 06	Temic SRS	OM97/20 or OM97/15 K2 or K9
Lancia	Thesis	02 - 06	TRW MY99	OM97/15 D1
Lancia	Y	96 - 03	Allied Signal, Allied MY97	OM98/16 or OM97/15 D1
Lancia	Ypsilon	03 - 06	Autoliv MY99	OM97/15 D1
Lancia	Z	96 - 02	Autoliv, Autoliv ACU	OM97/20 or OM97/15 K2 or K9
Land Rover	Freelander	98 - 02	Autoliv AC4	OM97/15 A1
Land Rover	Freelander	03 - 06	Siemens SRE Smart	OM97/15 A1
Land Rover	Discovery	96 - 98	TRW SPS	OM97/15 L11
Land Rover	Discovery II	98 - 04	TRW Generation 4	OM97/15 A1
Land Rover	Range Rover	97 - 02	TRW SPS	OM97/15 L11
Land Rover	New Range Rover	03 -	Bosch MRS4	OM97/15 F2
Mercedes	A Class (W168)	98 - 03	Fast Codes	OM97/15 B2 or K2

	Make	Model	From/To	System	Harness Required
New	Mercedes	A Class (W169)	04 -	AB 169	OM98/10
New	Mercedes	B Class (W245)	05 -	AB 169	OM98/10
	Mercedes	C Class (W202)	93 - 01	Fast Codes	OM97/15 B2 or K2
New	Mercedes	C Class (W203)	00 - 09/03	Arminca	OM97/15 B2 or K2
New	Mercedes	C Class (W203)	09/03 - 07	Armada	OM98/10
New	Mercedes	C Class (W203)	09/03 - 07	WSS	OM98/10
New	Mercedes	CL Class (W215)	99 - 09/02	Armin	OM97/15 B2 or K2
New	Mercedes	CL Class (W215)	09/02 - 06	Armada 2	OM98/10
	Mercedes	CLK (W208)	93 - 03	Fast Codes	OM97/15 B2 or K2
New	Mercedes	CLK (W209)	02 - 04/04	Arminca	OM98/10
New	Mercedes	CLK (W209)	04/04 - 02	Armada	OM98/10
New	Mercedes	CLK (W209)	04/04 - 02	WSS	OM98/10
New	Mercedes	CLS (W219)	04 -	Armada	OM98/10
New	Mercedes	CLS (W219)	04 -	RGSL 211	OM98/10
New	Mercedes	CLS (W219)	04 -	RGSR 211	OM98/10
New	Mercedes	CLS (W219)	04 -	WSS	OM98/10
	Mercedes	E Class (W210)	95 - 03	Fast Codes	OM97/15 B2 or K2
New	Mercedes	E Class (W211)	02 -	Armada	OM98/10
New	Mercedes	E Class (W211)	02 -	RGSL 211	OM98/10
New	Mercedes	E Class (W211)	02 -	RGSR 211	OM98/10
New	Mercedes	E Class (W211)	02 -	WSS	OM98/10
	Mercedes	G Class (W461)	98 - 02	Fast Codes	OM97/15 B2 or K2
	Mercedes	G Class (W463)	98 -	Fast Codes	OM98/10
New	Mercedes	G Class (W463)	98 -	Armin	OM98/10
	Mercedes	M Class (W163)	93 - 03	Fast Codes	OM97/15 B2 or K2
New	Mercedes	M Class (W164)	05 -	Arcade 164	OM98/10
New	Mercedes	M Class (W164)	05 -	RGSL 164	OM98/10
New	Mercedes	M Class (W164)	05 -	RGSR 164	OM98/10
New	Mercedes	M Class (W164)	05 -	WSS	OM98/10
New	Mercedes	R Class (251)	05 -	Arcade 164	OM98/10
New	Mercedes	R Class (251)	05 -	RGSL 164	OM98/10
New	Mercedes	R Class (251)	05 -	RGSR 164	OM98/10
New	Mercedes	R Class (251)	05 -	WSS	OM98/10
	Mercedes	S Class (W140)	91 - 08	Fast Codes	OM97/15 B2 or K2
	Mercedes	S Class (W220)	98 - 09/02	Fast Codes	OM98/10
New	Mercedes	S Class (W220)	09/02 -	Armada 2	OM98/10
New	Mercedes	S Class (W220)	09/02 -	REVASL	OM98/10
New	Mercedes	S Class (W220)	09/02 -	REVASR	OM98/10
New	Mercedes	S Class (W221)	05 -	Arcade 221	OM98/10
New	Mercedes	S Class (W221)	05 -	RGSL 221	OM98/10
New	Mercedes	S Class (W221)	05 -	RGSR 221	OM98/10
New	Mercedes	S Class (W221)	05 -	WSS 221	OM98/10
	Mercedes	SL (R129)	93 - 03	Fast Codes	OM97/15 B2 or K2
New	Mercedes	SL (R230)	03 - 06	Armada 2	OM98/10
	Mercedes	SLK (R170)	93 - 03	Fast Codes	OM97/15 B2 or K2
New	Mercedes	SLK (R171)	04 -	Armada	OM98/10

OmiInspect  
FASTCHECK AIRBAG



New  
New  
New  
New  
New

Make	Model	From/To	System	Harness Required
Mercedes	SLR (199)	04 -	Armada 2	OM98/10
Mercedes	Sprinter (W901 / W902 / W903 / W904)	95 - 02	Fast Codes	OM97/15 B2 or K2 and SB162/13
Mercedes	Vaneo (414)	02 -	Armin	OM97/15 B2 or K2
Mercedes	Viano (639)	03 -	Armada	OM97/15 B2 or K2
Mercedes	Vito (639)	03 -	Armada	OM97/15 B2 or K2
MINI	MINI (R50 / R53)	00 - 07	MRS 4	OM97/15 A6
Peugeot	1007	04 - 06	TRW Airbag	OM97/15 K2 or K9
Peugeot	106	96 - 00	Airbag / Seat Belt	OM97/20 or OM97/15 K2 or K9
Peugeot	106	00 - 04	Autoliv ACU	OM97/15 K2 or K9
Peugeot	206	98 - 00	Airbag / Seat Belt / Side Airbags	OM97/20 or OM97/15 K2 or K9
Peugeot	206	00 - 06	Autoliv ACU / Temic SRS	OM97/15 K2 or K9
Peugeot	306	96 - 00	Airbag / Seat Belt / Side Airbags	OM97/20 or OM97/15 K2 or K9
Peugeot	306	00 - 02	Autoliv ACU	OM97/15 K2 or K9
Peugeot	307	01 - 07	Temic SRS	OM97/15 K2 or K9
Peugeot	406	95 - 00	Airbag/ Seat Belt/ Side Airbags	OM97/20 or OM97/15 K2 or K9
Peugeot	406	00 - 03	Autoliv ACU	OM97/15 K2 or K9
Peugeot	407	05 -	Temic SRS	OM97/15 K2 or K9
Peugeot	605	97 - 00	Airbag/ Seat Belt/ Side Airbags	OM97/20 or OM97/15 K2 or K9
Peugeot	607	01 - 06	Temic SRS	OM97/15 K2 or K9
Peugeot	806	96 - 00	Airbag/ Seat Belt/ Side Airbags	OM97/20 or OM97/15 K2 or K9
Peugeot	806	00 - 03	Autoliv ACU	OM97/15 K2 or K9
Peugeot	807	02 -	Temic SRS	OM97/15 K2 or K9
Peugeot	Boxer	96 - 00	Breed SRS / Breed 97 MY / Siemens 99 MY	Use Fiat Ducato
Peugeot	Expert	97 - 00	Airbag/ Seat Belt	OM97/20 or OM97/15 K2 or K9
Peugeot	Expert	00 -	Autoliv ACU	OM97/15 K2 or K9
Peugeot	Partner/Ranch	96 - 00	Airbag/ Seat Belt	OM97/20 or OM97/15 K2 or K9
Peugeot	Partner/Ranch	00 -	Autoliv ACU / TRW Airbag	OM97/15 K2 or K9
Renault	Clio II	98 - 06	AB7	OM97/15 A1
Renault	Clio II	98 - 06	AB8	OM97/15 A1
Renault	Clio III	06 -	AB9	OM98/10
Renault	Laguna	93 - 00	AC6	OM97/15 A1
Renault	Laguna	93 - 00	AC6 Phase 2	OM97/15 A1
Renault	Laguna	93 - 00	EC5	OM97/15 A1
Renault	Megane	95 - 02	AC4	OM97/15 A1
Renault	Megane	95 - 02	AC4 Phase 2	OM97/15 A1
Renault	Megane	95 - 02	AC6	OM97/15 A1
Renault	Megane	95 - 02	AC6 Phase 2	OM97/15 A1
Renault	Megane	95 - 02	ACU 3.8	OM97/15 A1
Renault	Megane II	02 -	Siemens Autoliv ACU4 MK2	OM98/10
Renault	Modus	04 -	AB9	OM98/10
Renault	Scenic	95 - 02	EC5	OM97/15 A1
Renault	Scenic	95 - 02	AC4	OM97/15 A1
Renault	Scenic	95 - 02	AC4 Phase 2	OM97/15 A1
Renault	Scenic	95 - 02	AC6	OM97/15 A1
Renault	Scenic	95 - 02	AC6 Phase 2	OM97/15 A1
Renault	Scenic	95 - 02	EC5	OM97/15 A1

New  
New

Due to model changes, dates may not be precise. Try other leads or systems before contacting product support.  
Petrol vehicles MY2000 on (diesel MY2004 on) should be OBD II compliant and can be diagnosed via EOBD for emissions data.

New

Make	Model	From/To	System	Harness Required
Renault	Scenic II	03 -	Siemens Autoliv ACU4 MK2	OM98/10
Seat	Alhambra	96 -	KWP1281 / KW2000	OM97/15 A1
Seat	Altea	04 -	CAN	OM98/10
Seat	Arosa	97 - 05	KWP1281 / KW2000	OM97/15 A1
Seat	Cordoba	93 -	KWP1281 / KW2000	OM97/15 A1
Seat	Ibiza	93 -	KWP1281 / KW2000	OM97/15 A1
Seat	Leon	00 - 04	KWP1281 / KW2000	OM97/15 A1
Seat	Leon	04 -	CAN	OM98/10
Seat	Toledo	92 - 05	KWP1281 / KW2000	OM97/15 A1
Seat	Toledo III	04 -	CAN	OM98/10
Skoda	Fabia	00 - 07	KWP1281 / KW2000	OM97/15 A1
Skoda	Fabia II	07 -	CAN	OM98/10
Skoda	Felicia	95 - 04	KWP1281 / KW2000	OM97/15 A1
Skoda	Octavia	96 - 04	KWP1281 / KW2000	OM97/15 A1
Skoda	Octavia II	04 -	CAN	OM98/10
Skoda	Superb	02 - 04	KWP1281 / KW2000	OM97/15 A1
VW	Beetle	99 -	KWP1281 / KW2000	OM97/15 A1
VW	Bora	98 - 05	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Bora	05 -	CAN	OM98/10
VW	Cabrio	95 - 02	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Caddy	92 - 05	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Caddy	05 -	CAN	OM98/10
VW	Corrado	91 - 95	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	EOS	05 -	CAN	OM98/10
VW	Eurovan	99 - 03	KWP1281 / KW2000	OM98/10
VW	Golf/GTI	91 - 03	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Golf/GTI	03 -	CAN	OM98/10
VW	Golf Plus	05 -	CAN	OM98/10
VW	Jetta	93 - 04	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Jetta	05 -	CAN	OM98/10
VW	Lupo	98 - 05	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Passat	94 - 05	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Passat	05 -	CAN	OM98/10
VW	Phaeton	03 -	KWP1281 / KW2000	OM97/15 A1
VW	Polo	98 -	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Touareg	03 - 06	KWP1281 / KW2000	OM97/15 A1
VW	Touareg	07 -	CAN	OM98/10
VW	Touran	03 -	CAN	OM98/10
VW	Sharan	95 -	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Transporter/Caravelle	92 - 04	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Transporter/Caravelle T5	04 -	CAN	OM98/10
VW	Vento	92 - 98	KWP1281 / KW2000	OM98/10