



OmiNspect

Vehicle Application List - Version 4.0.0

This document should be used in conjunction with Operating Instructions.
The Operating Instructions will assist you in locating the correct vehicle connector and identifying the required interface cable.

Make	Model	From/To	System	Harness Required
Alfa Romeo	145	94 - 00	Bosch 5.3 ABS	OM98/16 or OM97/15 B1
Alfa Romeo	146	94 - 00	Bosch 5.3 ABS	OM98/16 or OM97/15 B1
Alfa Romeo	147	00 - 07	Bosch 5.7 ABS, Bosch 5.7 VDC, Bosch 5.7 ABS/ASR/TC, Bosch 8 ABS, Bosch 8 ASR, Bosch 8 VDC	OM97/15 B1
Alfa Romeo	155	95 - 97	Bosch 5.3 ABS	OM98/16 or OM97/15 B1
Alfa Romeo	156	97 - 02	Bosch 5.3 ABS	OM98/16 or OM97/15 B1
Alfa Romeo	156 '02	02 - 05	Bosch 5.7 ABS, Bosch 5.7 VDC, Bosch 5.7 ABS/ASR/TC	OM98/16 or OM97/15 B1
Alfa Romeo	159	05 -	TRW / Lucas ABS	OM97/15 B1
Alfa Romeo	164	88 - 98	Bosch 5.3 ABS	OM98/16 or OM97/15 B1
Alfa Romeo	166	98 - 03	Bosch 5.3 ABS, Bosch 5.3 TC ABS, Bosch 5.7 VDC	OM98/16 or OM97/15 B1
Alfa Romeo	33	88 - 89	Bosch 5.3 ASR ABS	OM98/16 or OM97/15 B1
Alfa Romeo	GT	04 -	Bosch 5.7 ABS, Bosch 5.7 VDC, Bosch 8 ABS, Bosch 8 VDC	OM97/15 B1
Alfa Romeo	GTV	95 - 03	Bosch 5.3 ABS	OM98/16 or OM97/15 B1
Alfa Romeo	Spider	95 - 03	Bosch 5.3 ABS	OM98/16 or OM97/15 B1
Audi	80/Cabrio/Coupe/Quattro	94 - 96	KWP1281	OM97/17
Audi	A2	00 - 04	KWP1281/KW2000	OM97/15 A1
Audi	A3	96 - 04	KWP1281/KW2000	OM97/15 A1
Audi	A3	04 -	CAN	OM98/10
Audi	A4	95 - 04	KWP1281/KW2000	OM97/15 A1
Audi	A4	04 -	CAN	OM98/10
Audi	S4	95 - 04	KWP1281/KW2000	OM97/15 A1
Audi	S4	04 -	CAN	OM98/10
Audi	A6	97 - 04	KWP1281/KW2000	OM97/15 A1
Audi	A6	04 -	CAN	OM98/10
Audi	S6	97 - 04	KWP1281/KW2000	OM97/15 A1
Audi	S6	04 -	CAN	OM98/10
Audi	Allroad Quattro	01 - 04	KWP1281/KW2000	OM97/15 A1
Audi	Q7	06 -	CAN	OM98/10
Audi	A8	94 - 04	KWP1281/KW2000	OM97/15 A1
Audi	A8	04 -	CAN	OM98/10
Audi	S8	94 - 04	KWP1281/KW2000	OM97/15 A1
Audi	S8	04 -	CAN	OM98/10
Audi	TT	98 - 07	KWP1281/KW2000	OM97/15 A1
Audi	TT	07 -	CAN	OM98/10
Audi	100	94 - 97	KWP1281/KW2000	OM97/17
BMW	1 Series (E81/E87)	04 - 03/07	Teves MK 60E, Teves MK 60E5	OM98/18
BMW	3 Series (E36)	90 - 98	ABS uC 3 Channel, ABS ASC ITT, ABS/ASC 5, Bosch ABS DSC3, Teves MK 20	OM97/11 or OM97/15 A6 / OM98/18
BMW	3 Series (E46)	98 - 05	ABS/DSC 5.7, Teves MK 20, Teves MK 60, Teves DSC III MK 60	OM97/11 or OM97/15 A6 / OM98/18
BMW	3 Series (E90/E91/E92/E93)	05 - 03/07	Bosch ABS DSCS8 Plus, Teves MK 60E, Teves MK 60E5	OM98/18
BMW	5 Series (E39)	96 - 04	ABS/ASC 5, ABS/ASC 5.7, ABS/DSC 5.7	OM97/11 or OM97/15 A6 / OM98/18
BMW	5 Series (E60/E61)	04 - 03/07	Bosch ABS DSC8, Bosch ABS DSCS8 Plus, Teves MK 60E5	OM98/18
BMW	6 Series (E63/E64)	05 - 03/07	Bosch ABS DSC8, Bosch ABS DSCS8 Plus, Teves MK 60E5	OM98/18
BMW	7 Series (E38)	94 - 02	ABS 5, ABS/ASC 5, BOSCH ABS DSC3	OM97/11 or OM97/15 A6 / OM98/18
BMW	7 Series (E65)	02 - 03/07	ABS/DSC5.7	OM98/18
BMW	8 Series (E31)	90 - 99	ABS 5, ABS/ASC 5, BOSCH ABS DSC3	OM97/11
BMW	X3 (E83)	03 -	DSC 8 X-Drive	OM97/15 A6 / OM98/18

Make	Model	From/To	System	Harness Required
BMW	X5 (E53)	00 -	ABS/DSC 5.7, DSC 8 X-Drive	OM97/15 A6 / OM98/18
BMW	Z3 (E36)	96 - 03	Bosch ABS DSC3, Teves MK 20	OM97/11 or OM97/15 A6 / OM98/18
BMW	Z4 (E85)	03 -	Teves DSC III MK 60, DSC MK60E5	OM97/15 A6
BMW	Z8 (E52)	00 - 03	ABS/DSC 5.7	OM97/11 or OM97/15 A6 / OM98/18
Citroen	Berlingo	96 - 04	Bosch 5.0 / 5,3 ABS	OM97/20 or OM97/15 J6
Citroen	C1	05 - 05	Bosch 8 ESP	OM97/20 or OM97/15 J6
Citroen	C2	03 - 05	Teves MK60 / MK70	OM97/20 or OM97/15 J6
Citroen	C3	02 - 05	Bosch 5.7 ESP / Teves MK60	OM97/20 or OM97/15 J6
Citroen	C4	04 - 05	Bosch 5.7 ESP / Teves MK60	OM97/20 or OM97/15 J6
Citroen	C5	00 - 05	Bosch 5.7 ESP / Teves MK60	OM97/20 or OM97/15 J6
Citroen	C8	02 - 05	Bosch 5.7 ESP / Teves MK60	OM97/20 or OM97/15 J6
Citroen	Dispatch/Jumpy	95 - 02	Bosch 5.3 ABS	OM97/20 or OM97/15 J6
Citroen	Evasion	97 - 03	Bosch 5.3 ABS	OM97/20 or OM97/15 J6
Citroen	Relay/Jumper	97 - 02	Bosch 5.3 ABS	OM97/20 or OM97/15 J6
Citroen	Saxo	98 - 03	Teves MK 20E/IE ABS / Teves 4-GI (ITT 04-GI) ABS	OM97/20 or OM97/15 J6
Citroen	Synergie	97 - 03	Bosch 5.3 ABS	OM97/20 or OM97/15 J6
Citroen	Xantia	98 - 02	Bosch 5.3 ABS / Teves MK 20E/IE ABS	OM97/20 or OM97/15 J6
Citroen	XM	96 - 01	Teves MK 20E/IE ABS	OM97/20 or OM97/15 J6
Citroen	Xsara	97 - 03	Bosch 5.3 ABS	OM97/20 or OM97/15 J6
Citroen	Xsara Picasso	99 - 03	Bosch 5.3 ABS / Bosch 5.7 ESP	OM97/20 or OM97/15 J6
Fiat	Barchetta	96 - 00	Bosch 5.3 ABS	OM98/16 or OM97/15 B1
Fiat	Coupe	96 - 02	Bosch 5.3 ABS	OM98/16 or OM97/15 B1
Fiat	Croma	93 - 96	Bosch 5.3 ABS	OM98/16 or OM97/15 B1
Fiat	Croma '05	05 -	TRW / Lucas ABS	OM97/15 B1
Fiat	Ducato	94 - 02	Bosch 5.3 ABS	OM98/16 or OM97/15 B1
Fiat	Ducato RST	01 -	Bosch 5.3 ABS, Bosch 5.3 ASR ABS	OM97/15 B1
Fiat	Idea	01 -	Bosch 5.3 ABS, Bosch 5.3 ASR ABS, Bosch 8 ABS, Bosch 8 VDC	OM97/15 B1
Fiat	Marea/Weekend	96 - 99	Lucas ABS	OM98/16 or OM97/15 B1
Fiat	Multipla	98 - 01	Bosch 5.3 ABS, Bosch 5.7 VDC ABS	OM98/16 or OM97/15 B1
Fiat	Multipla '02	02 -	Bosch 5.3 ABS, Bosch 5.7 VDC ABS	OM97/15 B1
Fiat	Palio	97 - 01	Bosch 5.3 ABS	OM98/16 or OM97/15 B1
Fiat	Palio RST	01 - 02	Bosch 5.3 ABS	OM97/15 B1
Fiat	Palio RST2	02 -	Bosch 5.3 ABS	OM97/15 B1
Fiat	Panda 03	03 -	Bosch 8 ABS, Bosch 8 VDC ABS	OM97/15 B1
Fiat	Punto	93 - 99	Bosch 5.3 ABS	OM98/16 or OM97/15 B1
Fiat	Punto '99	99 - 03	Bosch 5.3 ABS, Bosch 5.3 TC ABS	OM98/16 or OM97/15 B1
Fiat	Punto '03	03 - 05	Bosch 5.3 ABS, Bosch 8 ABS, Bosch 8 VDC ABS	OM98/16 or OM97/15 B1
Fiat	Scudo	97 - 01	Bosch 5.3 ABS	OM98/16 or OM97/15 B1
Fiat	Seicento	98 - 00	Bosch 5.3 ABS	OM98/16 or OM97/15 B1
Fiat	Stilo	01 -	Bosch 5.7 ABS, Bosch 5.7 VDC, Bosch 5.7 ABS/ASR/TC, Bosch 8 ABS, Bosch 8 VDC	OM97/15 B1
Fiat	Ulysse	97 - 02	Bosch 5.3 ABS	OM97/15 B1
Fiat	Ulysse '02	02 - 05	Bosch 5.7 ABS	OM97/15 B1
Ford	Cougar	99 - 02	ABS	OM98/10 or OM98/18
Ford	Crown Victoria	95 - 07	ABS	OM98/10 or OM98/18
Ford	Escort	95 - 02	ABS	OM98/10 or OM98/18

New

	Make	Model	From/To	System	Harness Required
New	Ford	Excursion	00 -	ABS	OM98/10 or OM98/18
New	Ford	Expedition	97 -	ABS	OM98/10 or OM98/18
	Ford	Explorer	96 -	ABS	OM98/10 or OM98/18
New	Ford	E-Series	97 - 08	ABS	OM98/10 or OM98/18
	Ford	F-250 Light Duty	97 - 02	ABS	OM98/10 or OM98/18
	Ford	Fiesta	96 -	ABS	OM98/10 or OM98/18
	Ford	Focus	99 - 06	ABS	OM98/10 or OM98/18
	Ford	Focus C-MAX	02 -	ABS	OM98/10 or OM98/18
	Ford	Fusion	02 -	ABS	OM98/10 or OM98/18
New	Ford	F-Series Super Duty	97 -	ABS	OM98/10 or OM98/18
New	Ford	Galaxy	00 - 06	ABS	OM98/10 or OM98/18
	Ford	Granada/Scorpio	94 - 98	ABS	OM98/10 or OM98/18
	Ford	GT	05 - 06	ABS	OM98/10 or OM98/18
	Ford	Ka	96 - 06	ABS	OM98/10 or OM98/18
	Ford	Street Ka	03 -	ABS	OM98/10 or OM98/18
	Ford	Maverick	01 - 04	ABS	OM98/10 or OM98/18
	Ford	Maverick 05	05 -	ABS	OM98/10 or OM98/18
	Ford	Mondeo III	95 - 06	ABS	OM98/10 or OM98/18
	Ford	Puma	97 - 01	ABS	OM98/10 or OM98/18
	Ford	Ranger	99 - 06	ABS	OM98/10 or OM98/18
	Ford	Transit	00 - 06	ABS	OM98/10 or OM98/18
	Ford	Transit / Torneo Connect	02 -	ABS	OM98/10 or OM98/18
New	Ford	WindStar	96 - 04	ABS	OM98/10 or OM98/18
	GM	Agila	00 - 08	Agila ABS	OM97/15 A2
	GM	Astra-F	92 - 97	Bosch 2E	OM97/15 J2
	GM	Astra-G	98 - 04	Bosch 5.3/5.4TC, ESP	OM97/15 A2
New	GM	Astra-H	04 -	Astra-H ABS/TC/ESP	OM98/10 or OM98/18
	GM	Calibra	90 - 97	Bosch 2E	OM97/15 J2
New	GM	Combo	02 - 06	Bosch5.3/5.4TC, Bosch 8	OM97/15 A2/J2
	GM	Corsa-B	97 - 01	Bosch 5.3	OM97/15 J2
	GM	Corsa-C	01 -06	Bosch5.3/5.4TC, Bosch 8	OM97/15 A2/J2
New	GM	Corsa-D	06 -	Corsa-D ABS/TC/ESP	OM98/10 or OM98/18
	GM	Frontera-A	95 - 98	Bosch 415	OM97/15 J2
	GM	Movano	04 - 06	ABS 430	OM97/15 A2
	GM	Meriva	03 - 08	Bosch 8	OM97/15 A2
	GM	Omega-B	94 - 03	Bosch 2SH, Bosch 5.3/5.4TC, ESP	OM97/15 A2/J2
New	GM	Signum	01 -	EBC430 ABS/TC/ESP	OM98/10 or OM98/18
	GM	Speedster / VX220	01 - 06	KH430	OM97/15 J2
	GM	Tigra-A	95 - 00	ABS 4/4F, Bosch 5.3	OM97/15 J2
	GM	Tigra-B	05 - 08	Bosch 8	OM97/15 A2
	GM	Vectra-B	96 - 01	Bosch 415, Bosch 5 TC, KH430, Bosch5.3/5.4TC	OM97/15 J2
New	GM	Vectra-C	01 -	EBC430 ABS/TC/ESP	OM98/10 or OM98/18
	GM	Vivaro	01 - 06	ABS 430	OM97/15 A2
	GM	Zafira-A	99 - 05	Bosch5.3/5.4TC, Bosch 8	OM97/15 A2
New	GM	Zafira-B	05 -	Zafira-B ABS/TC/ESP	OM98/10 or OM98/18
	Lancia	Dedra	94 - 99	Bosch 5.3 ABS	OM98/16 or OM97/15 B1

Make	Model	From/To	System	Harness Required	
Lancia	Delta	96 - 00	Bosch 5.3 ABS	OM98/16 or OM97/15 B1	
Lancia	Kappa	94 - 01	Bosch 5.3 ABS	OM98/16 or OM97/15 B1	
Lancia	Lybra	99 - 06	Bosch 5.3 ABS, Bosch 5.3 ASR ABS, TRW Lucas ESP ABS	OM98/16 or OM97/15 B1	
Lancia	Musa	04 - 06	Bosch 8 ABS, Bosch 8 VDC ABS	OM97/15 B1	
Lancia	Phedra	02 - 06	Bosch 5.7 ABS, Bosch 5.7 ESP	OM97/15 B1	
Lancia	Thesis	02 - 06	TRW / Lucas ABS	OM97/15 B1	
Lancia	Y	96 - 03	Bosch 5.3 ABS	OM98/16 or OM97/15 B1	
Lancia	Ypsilon	03 - 06	TRW / Lucas ABC, TRW / Lucas ESP ABS	OM97/15 B1	
Lancia	Z	96 - 02	Bosch 5.3 ABS	OM98/16 or OM97/15 B1	
Land Rover	Defender	99 - 03	Wabco D	OM97/15 A1	
Land Rover	Freelander	98 - 01	Wabco D	OM97/15 A1	
Land Rover	Freelander	01 - 06	ABS Mk25	OM97/15 K2	
Land Rover	Discovery II	99 - 04	Wabco D	OM97/15 A1	
Land Rover	Range Rover	99 - 03	Wabco D	OM97/15 A1	
Mercedes	A Class (W168)	98 - 03	ABS / ASR / ETS/ ESP / BAS*	OM97/15 G2 and/or OM97/65	
New	Mercedes	A Class (W169)	04 -	ESP 169	OM98/10
New	Mercedes	B Class (W245)	05 -	ESP 169	OM98/10
Mercedes	C Class (W202)	93 - 01	ABS / ASR / ETS/ ESP / BAS*	OM97/15 G2 and/or OM97/65	
New	Mercedes	C Class (W203)	00 - 09/03	ESP Mk25	OM97/15 G2
New	Mercedes	C Class (W203)	09/03 - 07	ESP Mk25 (CAN)	OM98/10
Mercedes	CL Class (W215)	99 - 06	ABS / ASR / ETS/ ESP / BAS*	OM97/15 G2 and/or OM97/65	
Mercedes	CLK (W208)	98 - 02	ABS / ASR / ETS/ ESP / BAS*	OM97/15 G2 and/or OM97/65	
New	Mercedes	CLK (W209)	02 - 04/04	ESP Mk25	OM97/15 G2
New	Mercedes	CLK (W209)	04/04 - 02	ESP Mk25 (CAN)	OM98/10
New	Mercedes	CLS (W219)	04 -	SBC/ESP	OM98/10
New	Mercedes	CLS (W219)	04 -	SBC (CAN)	OM98/10
Mercedes	E Class (W210)	95 - 03	ABS / ASR / ETS/ ESP / BAS*	OM97/15 G2 and/or OM97/65	
New	Mercedes	E Class (W211)	02 -	EHB FSG	OM97/15 G2
Mercedes	E Class (W211)	02 -	Sensotronic BC	OM97/15 G2	
New	Mercedes	E Class (W211)	02 -	SBC/ESP	OM98/10
New	Mercedes	E Class (W211)	02 -	SBC (CAN)	OM98/10
Mercedes	G Class (W461)	98 - 02	ABS / ASR / ETS/ ESP / BAS*	OM97/15 G2 and/or OM97/65	
Mercedes	G Class (W463)	98 -	ABS / ASR / ETS/ ESP / BAS*	OM97/15 G2 and/or OM97/65	
Mercedes	M Class (W163)	95 - 03	ABS / ASR / ETS/ ESP / BAS*	OM97/15 G2 and/or OM97/65	
New	Mercedes	M Class (W164)	05 -	ESP164	OM98/10
New	Mercedes	R Class (251)	05 -	ESP164	OM98/10
Mercedes	S Class (W140)	91 - 08	ABS / ASR / ETS/ ESP / BAS*	OM97/15 G2 and/or OM97/65	
Mercedes	S Class (W220)	98 - 05	ABS / ASR / ETS/ ESP / BAS*	OM97/15 G2 and/or OM97/65	
New	Mercedes	S Class (W221)	05 -	ABR	OM98/10
Mercedes	SL (R129)	93 - 03	ABS / ASR / ETS/ ESP / BAS*	OM97/15 G2 and/or OM97/65	
Mercedes	SL (R230)	03 - 06	ABS / ASR / ETS/ ESP / BAS*	OM97/15 G2 and/or OM97/65	
New	Mercedes	SL (R230)	03 - 06	EHB FSG	OM97/15 G2 and/or OM97/65
Mercedes	SL (R230)	03 - 06	Sensotronic BC	OM97/15 G2 and/or OM97/65	
New	Mercedes	SL (R230)	03 - 06	SBC/ESP	OM98/10
New	Mercedes	SL (R230)	03 - 06	SBC (CAN)	OM98/10
Mercedes	SLK (R170)	91 - 04	ABS / ASR / ETS/ ESP / BAS*	OM97/15 G2 and/or OM97/65	

New
New
New

Make	Model	From/To	System	Harness Required
Mercedes	SLK (R171)	04 -	ESP Mk25 (CAN)	OM98/10
Mercedes	SLR (199)	04 -	EHB FSG	OM97/15 G2
Mercedes	SLR (199)	04 -	Sensotronic BC	OM97/15 G2
Mercedes	Sprinter (W901 / W902 / W903 / W904)	95 - 02	ABS / ASR / ETS/ ESP	OM97/15 G2 and/or SB162/13
*For BAS (if present) try switch positions G2, D2, F2				
MINI	MINI (R50 / R53)	00 - 07	Teves MK 60, Teves DSC III MK 60	OM97/15 A6
Peugeot	1007	04 - 05	Teves MK60	OM97/20 or OM97/15 J6
Peugeot	106	96 - 04	Teves 4-GI (ITT 04-GI) ABS / Teves MK 20E/IE ABS	OM97/20 or OM97/15 J6
Peugeot	107	05 - 05	Bosch 8 ESP	OM97/20 or OM97/15 J6
Peugeot	206	98 - 05	Teves MK 20E/IE ABS / Teves MK60 / Teves MK70	OM97/20 or OM97/15 J6
Peugeot	306	93 - 02	Bosch 5.0 ABS / Bosch 5.3 ABS	OM97/20 or OM97/15 J6
Peugeot	307	01 - 07	Bosch 5.3 ABS / Bosch 5.7 ESP / Bosch 8 ESP	OM97/20 or OM97/15 J6
Peugeot	406	95 - 03	Bosch 5.0 ABS / Bosch 5.3 ABS	OM97/20 or OM97/15 J6
Peugeot	605	96 - 00	Bosch 5.0 ABS / Bosch 5.3 ABS	OM97/20 or OM97/15 J6
Peugeot	607	00 - 03	Bosch 5.3 ABS / Bosch 5.7 ESP	OM97/20 or OM97/15 J6
Peugeot	806	97 - 03	Bosch 5.3 ABS	OM97/20 or OM97/15 J6
Peugeot	807	02 - 05	Bosch 5.7 ESP	OM97/20 or OM97/15 J6
Peugeot	Boxer	97 - 01	Bosch 5.3 ABS	OM97/20 or OM97/15 J6
Peugeot	Expert	97 - 03	Bosch 5.3 ABS	OM97/20 or OM97/15 J6
Peugeot	Partner / Ranch	96 - 03	Bosch 5.3 ABS	OM97/20 or OM97/15 J6
Renault	Clio		Bosch 5.0 / Bosch 5.3/5.3T	OM97/15 A1
Renault	Megane	98-03	Bosch 5.0 / Bosch 5.3/5.3T	OM97/15 A1
Renault	Megane II	03 -	ABS 8 v3.0	OM98/10
Renault	Kangoo	01 -	Bosch 8 ESP	OM97/15 A1
Renault	Laguna	98 - 01	Bosch 5.3/5.3T / Teves MK 20	OM97/15 A1
Renault	Laguna II	99-03	Teves MK 60	OM97/15 A1
Renault	Scenic	98-03	Bosch 5.0 / Bosch 5.3/5.3T	OM97/15 A1
Renault	Scenic II	03 -	ABS 8 v3.0	OM98/10
Seat	Alhambra	96 -	KWP1281 / KW2000	OM97/15 A1
Seat	Altea	04 -	CAN	OM98/10
Seat	Arosa	97 - 05	KWP1281 / KW2000	OM97/15 A1
Seat	Cordoba	93 -	KWP1281 / KW2000	OM97/15 A1
Seat	Ibiza	93 -	KWP1281 / KW2000	OM97/15 A1
Seat	Leon	00 - 04	KWP1281 / KW2000	OM97/15 A1
Seat	Leon	04 -	CAN	OM98/10
Seat	Toledo	92 - 05	KWP1281 / KW2000	OM97/15 A1
Seat	Toledo III	04 -	CAN	OM98/10
Skoda	Fabia	00 - 07	KWP1281 / KW2000	OM97/17 or OM97/15 A1
Skoda	Fabia II	07 -	CAN	OM98/10
Skoda	Octavia	96 - 04	KWP1281 / KW2000	OM97/17 or OM97/15 A1
Skoda	Octavia II	04 -	CAN	OM98/10
Skoda	Superb	02 -	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Beetle	99 -	KWP1281 / KW2000	OM97/15 A1
VW	Bora	98 - 05	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Bora	05 -	CAN	OM98/10
VW	Cabrio	95 - 02	KWP1281 / KW2000	OM97/17 or OM97/15 A1

Make	Model	From/To	System	Harness Required
VW	Caddy	92 - 05	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Caddy	05 -	CAN	OM98/10
VW	Corrado	91 - 95	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	EOS	05 -	CAN	OM98/10
VW	Eurovan	99 - 03	KWP1281/KW2000	OM98/10
VW	Golf/GTI	92 - 03	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Golf/GTI	03 -	CAN	OM98/10
VW	Golf Plus	05 -	CAN	OM98/10
VW	Jetta	92 - 04	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Jetta	05 -	CAN	OM98/10
VW	Lupo	98 - 05	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Passat	94 - 05	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Passat	05 -	CAN	OM98/10
VW	Phaeton	03 -	KWP1281 / KW2000	OM97/15 A1
VW	Polo	98 -	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Touareg	03 - 06	KWP1281 / KW2000	OM97/15 A1
VW	Touareg	07 -	CAN	OM98/10
VW	Touran	03 -	CAN	OM98/10
VW	Sharan	95 -	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Transporter/Caravelle	92 - 04	KWP1281 / KW2000	OM97/17 or OM97/15 A1
VW	Transporter/Caravelle T5	04 -	CAN	OM98/10
VW	Vento	92 - 98	KWP1281 / KW2000	OM98/10

OmiInspect
FASTCHECK EPB (Electronic Parking Brake)



New
New
New
New
New

Make	Model	From/To	System	Harness Required
Audi	A6	04 -	EPB	OM98/10
Audi	S6	04 -	EPB	OM98/10
Audi	A8	04 -	EPB	OM98/10
Ford	C-Max	03 -	EPB	OM98/10
Ford	S-Max	06 -	EPB	OM98/10
Ford	Transit	01 - 05	EPB	OM98/10
Mercedes	CLS (W219)	04 -	SBC (CAN)	OM98/10
Mercedes	E Class (W211)	02 -	Sensotronic BC	OM97/15 G2
Mercedes	E Class (W211)	02 -	SBC (CAN)	OM98/10
Mercedes	SL (R230)	03 - 06	Sensotronic BC	OM97/15 G2 and/or OM97/65
Mercedes	SL (R230)	03 - 06	SBC (CAN)	OM98/10
Mercedes	SLR (199)	04 -	Sensotronic BC	OM97/15 G2
Renault	Megane II	03 -	EPB	OM98/10
Renault	Scenic II	02 -	EPB	OM98/10
Renault	Espace IV	02 -	EPB	OM98/10
Renault	Vel Satis	01 -	EPB	OM98/10
VW	Passat	05 -	EPB	OM98/10