



OmiNspect

Vehicle Application List - Version 4.0.0

This document should be used in conjunction with Operating Instructions.
The Operating Instructions will assist you in locating the correct vehicle connector and identifying the required interface cable.

Make	Model	From/To	System	Harness Required
Citroen	C4	04 -	Schrader TPMS	OM98/10 and OM147/13
Citroen	C5	99 - 05	Schrader TPMS	OM97/15 I1
Citroen	C5 II	04 -	Schrader TPMS	OM98/10 and OM147/13
Citroen	C6	06 -	Schrader TPMS	OM98/10 and OM147/13
Citroen	C8	02 -	Schrader TPMS	OM97/15 I1
Fiat	Ulysse	94 - 05	Schrader TPMS	OM97/15 I1
Lancia	Phedra	02 - 06	Schrader TPMS	OM97/15 I1
Peugeot	307 II	05 -	Schrader TPMS	OM98/10 and OM147/13
Peugeot	407	04 -	Schrader TPMS	OM98/10 and OM147/13
Peugeot	607	99 -	Schrader TPMS	OM97/15 I1
Peugeot	607 II	04 -	Schrader TPMS	OM98/10 and OM147/13
Peugeot	807	02 -	Schrader TPMS	OM97/15 I1
Renault	Espace IV	03 -	Central Body Electrics - Renault TPMS	OM98/10 or OM97/15 A1
Renault	Laguna II	00 -	Central Body Electrics - Renault TPMS	OM98/10 or OM97/15 A1
Renault	Megane II	02 -	Central Body Electrics - Renault TPMS	OM98/10
Renault	Scenic II	03 -	Central Body Electrics - Renault TPMS	OM98/10
Renault	Vel Satis	00 -	Central Body Electrics - Renault TPMS	OM98/10 or OM97/15 A1