

FASTCHECK TPMS

Make	Model	From/To	System	Harness Required
Citroen	C4	04 -	Schrader TPMS	OM3000/10
Citroen	C5	99 - 05	Schrader TPMS	OM3000/10
Citroen	C5 II	04 -	Schrader TPMS	OM3000/10
Citroen	C6	06 -	Schrader TPMS	OM3000/10
Citroen	C8	02 -	Schrader TPMS	OM3000/10
Fiat	Punto '05 (Grande Punto)	05 -	TRW Tyre Pressure Control (EP)	OM3000/10
Fiat	Ulysse	94 - 05	Schrader TPMS	OM3000/10
Ford	Explorer	04 -	TPMS	OM3000/10
Ford	Focus	04 -	TPMS	OM3000/10
Ford	Focus C-Max	03 -	TPMS	OM3000/10
Ford	Expedition	05 -	TPMS	OM3000/10
GM	Vectra-C	02 -	TPMS	OM3000/10
GM	Signum	02 -	TPMS	OM3000/10
GM	Astra-H	04 -	TPMS	OM3000/10
GM	Zafira-B	05 -	TPMS	OM3000/10
Lancia	Phedra	02 - 06	Schrader TPMS	OM3000/10
Land Rover	Discovery III (L319)	05 -	TPMS	OM3000/10
Land Rover	Range Rover (L322)	07 -	TPMS	OM3000/10
Land Rover	Range Rover Sport (L320)	05 -	TPMS	OM3000/10
Peugeot	307 II	05 -	Schrader TPMS	OM3000/10
Peugeot	407	04 -	Schrader TPMS	OM3000/10
Peugeot	607	99 -	Schrader TPMS	OM3000/10
Peugeot	607 II	04 -	Schrader TPMS	OM3000/10
Peugeot	807	02 -	Schrader TPMS	OM3000/10
Renault	Clio III	05 -	Central Body Electrics - Renault TPMS	OM3000/10
Renault	Espace IV	03 -	Central Body Electrics - Renault TPMS	OM3000/10
Renault	Laguna II	00 -	Central Body Electrics - Renault TPMS	OM3000/10
Renault	Megane II	02 -	Central Body Electrics - Renault TPMS	OM3000/10
Renault	Scenic II	03 -	Central Body Electrics - Renault TPMS	OM3000/10
Renault	Vel Satis	00 -	Central Body Electrics - Renault TPMS	OM3000/10