

Mercedes Benz Coverage Version '7'

Features :

PREMIUM- & ULTIMATE features

→	Module / ECU Info
→	Read Stored Fault Codes
→	Read Actual Fault Codes
→	Erase Fault Codes
→	Service Interval History
→	Service Interval Reset
→	Service Interval Programming
→	Real Time Reading of Dynamic Data (live Data)
→	System Function Test
→	Smooth Running Test
→	Component Activation
→	Clear and Re-set Adaptation values
→	Calibration-, Alignment-, Synchronization- and other ECU adjustment Features

ULTIMATE (additional features)

→	Coding of Control Units
→	Conversion of Control Units
→	Individualization of Control Units
→	Retrofitting- , Programming- & Activating New Components
→	Fault Code Explanations
→	Step by Step Repair Instructions
→	Component Information and Locations
→	Complete Wiring Diagrams with Active Legends

Modules :

Drive Line

IFI	- Diesel Engine Control Unit
DFI	- Diesel Engine Management
CDI	- Diesel Engine Management
PMS	- Petrol Engine Management
HFM	- Petrol Engine Management
LH	- Petrol Engine Management

ME	- Petrol Engine Management
MSM	- Petrol Engine Management
EGS	- Electronic Transmission Control
ESM	- Electronic Selector Control Unit

Chassis	
ABS	- ABS Control Unit
ESP	- Traction Control
ABR	- Adaptive Brake System
BAS	- Brake Assistant Module
SBC	- Sensitive Brake Control Unit

Body	
AAM	- All Activity Module
AB	- Airbag
ABC	- Active Body Control
AHE	- Trailer Recognition Module
AirMatic	- Airmatic System
ATA	- Anti Theft Alarm Control Unit
BSG	- Battery Control Module
CGW	- Central Gateway Module
DAS	- Drive Authorisation System
DCM	- Door Control Module
DCM 1	- Door Control Module 1
DCM 2	- Door Control Module 2
DCM 3	- Door Control Module 3
DCM 4	- Door Control Module 4
DCM FL	- Door Control Module Front Left
DCM FR	- Door Control Module Front Right
DCM RL	- Door Control Module Rear Left
DCM RR	- Door Control Module Rear Right
DM	- Diagnostic Module
EAM	- Enhanced Activity Module
EIS	- Electronic Ignition System
ESA FL	- Electronic Seat Adjustment Front Left
ESA FR	- Electronic Seat Adjustment Front Right
HRA	- Headlight Range Adjustment
KG	- Keyless Go
LCP	- Lower Control Panel

LWR FL	- Headlight Range Adjustment Front Left
LWR FR	- Headlight Range Adjustment Front Right
OCP	- Overhead Control Panel
PSE	- Pneumatic Control System
PTS	- Parktronic System
RST	- Roadster Soft Top
REVGUS FL	- Reversible emergency tensioning retractor front left
REVGUS FR	- Reversible emergency tensioning retractor front right
SAM	- Signal Acquisition Module
SAM V	- Front Signal Acquisition Module
SAM VL	- Front Left Signal Acquisition Module
SAM VR	- Front Right Signal Acquisition Module
SAM R	- Rear Signal Acquisition Module
SIH	- Seat Heating
UCP	- Upper Control Panel
UVS	- Rollover Bar / Vario Roof Module
VD	- Vario Roof
WSP	- Electronic Drive Away Protection
XALWA FL	- Headlight Range Adjustment Front Left
XALWA FR	- Headlight Range Adjustment Front Right
MSS	- Multifunction Module

Info & Communication

AGW	- Audio Gateway
CDC	- CD System
COMMAND	- Command System
CTEL	- Telephone
D2B	- D2B System
IC	- Instrument Cluster
NAVI	- Navigation System
SCM	- Steering Column Module
SCCN	- Steering Column Module
SYSTEM	- System Module
Assyst	- Module
Assyst Plus	- Module

AIRCO

AIRCO	- Air-Conditioning System
--------------	----------------------------------

Vehicles : *

A Class	- W168 - W169 - W414 (Vaneo)
B Class	- W245
C Class	- W202 - W203 - W204
CLK	- W208 - W209
E Class	- W124 - W210 - W211 - W212 - W207
CLS	- W219
SLK	- R170 - R171
SLR	- R199
R Class	- W251
ML	- W163 - W164
GL	- X164
GLK	- X204
G	- W461 - W463
S Class	- W140 - W220 - W221
CL	- W215 - W216
SL	- R129 - R230
V Class	- W638 - W639