

Kia Test coverage

V.22.0

Updated Date: 2007-12-08

MODEL	SYSTEM	SUB SYSTEM	FUNCTIONS
01.PRIDE 2003	01. ENGINE CONTROL	01. 1.3L SOHC GASOLINE MAP	1、 Read trouble codes
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
02.PRIDE 2002	01. ENGINE CONTROL	01. 1.3L SOHC GASOLINE MAP	1、 Read trouble codes
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
03.PRIDE 1999	01. ENGINE CONTROL	01. 1.3L SOHC GASOLINE MAP	1、 Read trouble codes
04.PRIDE 1998	01. ENGINE CONTROL	01. 1.3L SOHC GASOLINE MAP	1、 Read trouble codes
05.PRIDE BEFORE 1998	01. ENGINE CONTROL	01. 1.3L SOHC GASOLINE MAP	1、 Read trouble codes
06.VISTO ALL	01.ENGINE L4-SOHC	01. UNLEAD ALL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02. UNLEAD IMMO	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		03. LEAD ALL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG		1、 Read trouble codes 2、 Data Stream
07.AVELLA ALL	01.ENGINE CONTROL	01.1.3/1.5 ENGINE MAP	1、 Read trouble codes 2、 Data Stream
08.RIO 2003	01.ENGINE CONTROL	01. 1.3L/1.5L GASOLINE MAP	1、 Read trouble codes 2、 Data Stream
		02. 1.3L/1.5L MAF	1、 Read trouble codes 2、 Data Stream

AUTOBD NETWORK CO.,LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China

Tel/Fax: 0086-20-62853799

Website: www.autobd.net



		03. 1.3L/1.5L (RHD MAP	1、 Read trouble codes 2、 Data Stream	
		04. 1.3L/1.5L (RHD) MAF	1、 Read trouble codes 2、 Data Stream	
		05. 1.3L/1.5L GASOLINE W/IMMO	1、 Read trouble codes 2、 Data Stream	
		06. 1.3L/1.5L GASOLINE LEAD	1、 Read trouble codes 2、 Data Stream	
	02.AUTOMATIC TRANSAXLE	01. TCU LHD	1、 Read trouble codes 2、 Data Stream	
		02. TCU RHD	1、 Read trouble codes 2、 Data Stream	
	03.ANTI-LOCK BRAKE SYSTEM	01. DLC CABLE 16	1、 Read trouble codes 2、 Data Stream 3、 Actuations 4、 Deflation	
		02. 20PIN RED KIA CONNECTOR	1、 Read trouble codes 2、 Data Stream 3、 Actuations 4、 Deflation	
	04.SRS-AIRBAG	01. A/BAG LHD	1、 Read trouble codes 2、 Data Stream	
		02. A/BAG RHD	1、 Read trouble codes 2、 Data Stream	
09.RIO 2001-2002	01.ENGINE CONTROL	01. 1.3L/1.5L GASOLINE MAP	1、 Read trouble codes 2、 Data Stream	
		02. 1.3L/1.5L MAF	1、 Read trouble codes 2、 Data Stream	
		03. 1.3L/1.5L (RHD MAP	1、 Read trouble codes 2、 Data Stream	
		04. 1.3L/1.5L (RHD) MAF	1、 Read trouble codes 2、 Data Stream	
		05. 1.3L/1.5L GASOLINE W/IMMO	1、 Read trouble codes 2、 Data Stream	
		06. 1.3L/1.5L GASOLINE LEAD	1、 Read trouble codes 2、 Data Stream	
	02.AUTOMATIC TRANSAXLE	01. TCU LHD	1、 Read trouble codes 2、 Data Stream	
		02. TCU RHD	1、 Read trouble codes 2、 Data Stream	
	03.ANTI-LOCK BRAKE SYSTEM	01. ABS LHD	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		02. ABS RHD	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
	04.SRS-AIRBAG	01. A/BAG LHD	1、 Read trouble codes 2、 Data Stream	
		02. A/BAG RHD	1、 Read trouble codes 2、 Data Stream	
	10.RIO 2000	01.ENGINE CONTROL	01. 1.3L/1.5L GASOLINE MAP	1、 Read trouble codes 2、 Data Stream
			02. 1.3L/1.5L MAF	1、 Read trouble codes 2、 Data Stream
03. 1.3L/1.5L (RHD MAP			1、 Read trouble codes 2、 Data Stream	

AUTOBD NETWORK CO.,LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China

Tel/Fax: 0086-20-62853799

Website: www.autoibd.net



		04. 1.3L/1.5L (RHD) MAF	1、 Read trouble codes 2、 Data Stream	
		05. 1.3L/1.5L GASOLINE W/IMMO	1、 Read trouble codes 2、 Data Stream	
		06. 1.3L/1.5L GASOLINE LEAD	1、 Read trouble codes 2、 Data Stream	
	02.AUTOMATIC TRANSAXLE	01. TCU LHD	1、 Read trouble codes 2、 Data Stream	
		02. TCU RHD	1、 Read trouble codes 2、 Data Stream	
	03.ANTI-LOCK BRAKE SYSTEM	01. ABS LHD	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		02. ABS RHD	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
	04.SRS-AIRBAG	01. A/BAG LHD	1、 Read trouble codes 2、 Data Stream	
		02. A/BAG RHD	1、 Read trouble codes 2、 Data Stream	
	11.SEPHIA 2003	01.ENGINE CONTROL	01.1.6L DOHC NON IMMO	1、 Read trouble codes 2、 Data Stream
02.1.6L DOHC W/IMMO			1、 Read trouble codes 2、 Data Stream	
03.1.6L DOHC LEAD			1、 Read trouble codes 2、 Data Stream	
04. 1.8L DOHC GASOLINE TED			1、 Read trouble codes 2、 Data Stream	
02.AUTOMATIC TRANSAXLE			1、 Read trouble codes 2、 Data Stream	
03.ANTI-LOCK BRAKE SYSTEM			1、 Read trouble codes 2、 Data Stream 3、 Actuations	
04.SRS-AIRBAG			1、 Read trouble codes	
12.SEPHIA 2002		01.ENGINE CONTROL	01.1.6L DOHC NON IMMO	1、 Read trouble codes 2、 Data Stream
			02.1.6L DOHC W/IMMO	1、 Read trouble codes 2、 Data Stream
			03.1.6L DOHC LEAD	1、 Read trouble codes 2、 Data Stream
	04. 1.8L DOHC GASOLINE TED		1、 Read trouble codes 2、 Data Stream	
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream	
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations	

AUTOBD NETWORK CO.,LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China

Tel/Fax: 0086-20-62853799

Website: www.autoibd.net



	04.SRS-AIRBAG		1、 Read trouble codes
13.SEPHIA 2001	01.ENGINE CONTROL	01.1.6L DOHC NON IMMO	1、 Read trouble codes 2、 Data Stream
		02.1.6L DOHC W/IMMO	1、 Read trouble codes 2、 Data Stream 流
		03.1.6L DOHC LEAD	1、 Read trouble codes 2、 Data Stream
		04. 1.8L DOHC GASOLINE TED	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG		1、 Read trouble codes
14.SEPHIA 2000	01.ENGINE CONTROL	01.1.5L GASOLINE BFD/BFES	1、 Read trouble codes 2、 Data Stream
		02.1.8L DOHC GASOLINE TED	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG		1、 Read trouble codes
15.SEPHIA 1999	01.ENGINE CONTROL	01.1.5L GASOLINE BFD/BFES	1、 Read trouble codes 2、 Data Stream
		02.1.8L DOHC GASOLINE TED	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG		1、 Read trouble codes
16.SEPHIA 1998	01.ENGINE CONTROL	01.1.5L GASOLINE BFD/BFES	1、 Read trouble codes 2、 Data Stream
		02.1.8L DOHC GASOLINE TED	1、 Read trouble codes 2、 Data Stream

AUTOBD NETWORK CO.,LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China

Tel/Fax: 0086-20-62853799

Website: www.autoibd.net



	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG		1、 Read trouble codes
17.SEPHIA BEFORE 1998			
18.SHUMA 2003	01.ENGINE CONTROL	01.1.6L DOHC NON IMMO	1、 Read trouble codes 2、 Data Stream
		02.1.6L DOHC W/IMMO	1、 Read trouble codes 2、 Data Stream
		03.1.6L DOHC LEAD	1、 Read trouble codes 2、 Data Stream
		04.1.8L DOHC GASOLINE TED	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG		1、 Read trouble codes
19.SHUMA 2002	01.ENGINE CONTROL	01.1.6L DOHC NON IMMO	1、 Read trouble codes 2、 Data Stream
		02.1.6L DOHC W/IMMO	1、 Read trouble codes 2、 Data Stream
		03.1.6L DOHC LEAD	1、 Read trouble codes 2、 Data Stream
		04.1.8L DOHC GASOLINE TED	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG		1、 Read trouble codes
20.SHUMA 2001	01.ENGINE CONTROL	01.1.6L DOHC NON IMMO	1、 Read trouble codes 2、 Data Stream
		02.1.6L DOHC W/IMMO	1、 Read trouble codes 2、 Data Stream

AUTOBD NETWORK CO.,LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China

Tel/Fax: 0086-20-62853799

Website: www.autoibd.net



		03.1.6L DOHC LEAD	1、 Read trouble codes 2、 Data Stream
		04.1.8L DOHC GASOLINE TED	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG		1、 Read trouble codes
21.SHUMA 2000	01.ENGINE CONTROL	01.1.5L GASOLINE BFD/BFE	1、 Read trouble codes 2、 Data Stream
		02.1.8L DOHC GASOLINE TED	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG		1、 Read trouble codes
22.SHUMA 1999	01.ENGINE CONTROL	01.1.5L GASOLINE BFD/BFE	1、 Read trouble codes 2、 Data Stream
		02.1.8L DOHC GASOLINE TED	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG		1、 Read trouble codes
23.CARENS 2003	01.ENGINE CONTROL	01. 2.0L DIESEL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02. 1.6L DOHC W/IMMO	1、 Read trouble codes 2、 Data Stream
		03. 1.6L DOHC EURP-IV	1、 Read trouble codes 2、 Data Stream
		04. 1.8L DOHC NON IMMO	1、 Read trouble codes 2、 Data Stream
		05. 1.8L DOHC W/IMMO	1、 Read trouble codes 2、 Data Stream

AUTOBD NETWORK CO.,LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China

Tel/Fax: 0086-20-62853799

Website: www.autoibd.net



		06. 1.8L DOHC EURO-IV	1、 Read trouble codes 2、 Data Stream
		07. 1.8L DOHC LEAD	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE	01. DIESEL	1、 Read trouble codes 2、 Data Stream
		02. GASOLINE	1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM	01. DLC CABLE 16	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02. 20PIN RED KIA CONNECTOR	1、 Read trouble codes 2、 Data Stream 3、 Actuations
04.SRS-AIRBAG		1、 Read trouble codes 2、 Data Stream	
24.CARENS 2002	01.ENGINE CONTROL	01.1.8L DOHC M/T	1、 Read trouble codes 2、 Data Stream
		02.1.8L DOHC	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG		1、 Read trouble codes
25.CARENS 2001	01.ENGINE CONTROL	01.1.8L DOHC M/T	1、 Read trouble codes 2、 Data Stream
		02.1.8L DOHC	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG		1、 Read trouble codes
26.CARENS 2000	01.ENGINE CONTROL	01.1.8L DOHC GASOLINE TED	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations

AUTOBD NETWORK CO.,LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China

Tel/Fax: 0086-20-62853799

Website: www.autoobd.net



	04.SRS-AIRBAG		1、 Read trouble codes
27.CARENS 1999	01.ENGINE CONTROL	01.1.8L DOHC GASOLINE TED	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG		1、 Read trouble codes
28.SPORTAGE 2003	01.ENGINE CONTROL	01.2.0L DOHC(HFM) BOSCH	1、 Read trouble codes 2、 Data Stream
		02.2.0L DOHC(HFM) LEAD	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	02.AUTOMATIC TRANSAXLE	01. TCU GASOLINE	1、 Read trouble codes 2、 Data Stream
		02. TCU DIESEL	1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM	01. ABS GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02. ABS DIESEL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
29.SPORTAGE 2002	01.ENGINE CONTROL	01.2.0L DOHC(HFM) BOSCH	1、 Read trouble codes 2、 Data Stream
		02.2.0L DOHC(HFM) LEAD	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	02.AUTOMATIC TRANSAXLE	01.TCU GASOLINE	1、 Read trouble codes 2、 Data Stream
		02.TCU DIESEL	1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM	01.ABS GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02.ABS DIESEL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
30.SPORTAGE 2001	01.ENGINE CONTROL	01.2.0L DOHC(HFM) BOSCH	1、 Read trouble codes 2、 Data Stream
		02.2.0L DOHC(HFM) LEAD	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM	01.ABS GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02.ABS DIESEL	1、 Read trouble codes 2、 Data Stream 3、 Actuations

AUTOBD NETWORK CO.,LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China

Tel/Fax: 0086-20-62853799

Website: www.autoibd.net



31.SPORTAGE 2000	01.ENGINE CONTROL	01.2.0L DOHC(HFM) UNLEAD	1、 Read trouble codes 2、 Data Stream
		02.UNLEAD(AUS)	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE	03.2.0L DOHC(HFM) LEAD	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		01.GASOLINE/DIESEL	1、 Read trouble codes 2、 Data Stream
32.SPORTAGE 1999	01.ENGINE CONTROL	02.UNLEAD(AUS)	1、 Read trouble codes 2、 Data Stream
		01.2.0L DOHC(HFM) UNLEAD	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE	02.2.0L DOHC(HFM) LEAD	1、 Read trouble codes 2、 Data Stream
33.SPORTAGE 1998	01.ENGINE CONTROL	02.2.0L DOHC(HFM) LEAD	1、 Read trouble codes 2、 Data Stream
		01.2.0L DOHC(HFM) UNLEAD	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
34.SPORTAGE BEFORE 1998	01.ENGINE CONTROL	01. 2.0L GASOLINE	1、 Read trouble codes 2、 Data Stream
35.CLARUS 2000	01.ENGINE CONTROL	01. 1.8L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02. 2.0L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG		1、 Read trouble codes
36.CLARUS 1999	01.ENGINE CONTROL	01. 1.8L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02. 2.0L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream

AUTOBD NETWORK CO.,LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China

Tel/Fax: 0086-20-62853799

Website: www.autobd.net



	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations	
	04.SRS-AIRBAG		1、 Read trouble codes	
37.CLARUS 1998	01.ENGINE CONTROL	01. 1.8L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		02. 2.0L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream	
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations	
	04.SRS-AIRBAG		1、 Read trouble codes	
38.CLARUS BEFORE 1998	01.ENGINE CONTROL	01. 1.8L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		02. 2.0L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
	02. SRS-AIRBAG		1、 Read trouble codes	
39.OPTIMA(MAGENTIS) 2003	01.ENGINE CONTROL	01. 2.7L V6 GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		02. 2.5L V6 EURO-III	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		03. 2.5L V6 GENERAL	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		04. 2.5L V6 LEAD	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		05. 2.4L DOHC MELCO	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		06. 2.4L DOHC A/T MELCO	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		07. 2.0L DOHC A/T LEAD	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		08. 2.0L DOHC M/T MELCO	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
	02.AUTOMATIC TRANSAXLE	01. TCU for 2.5L/2.7L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		02. TCU for 2.4L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		03. TCU for 2.0L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
				1、 Read trouble codes 2、 Data Stream 3、 Actuations

AUTOBD NETWORK CO., LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China

Tel/Fax: 0086-20-62853799

Website: www.autobd.net



	SYSTEM			
	04.SRS-AIRBAG		1、 Read trouble codes 2、 Data Stream	
40.OPTIMA(MAGENTIS) 2002	01.ENGINE CONTROL	01. 2.7L V6 GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		02. 2.5L V6 EURO-III	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		03. 2.5L V6 GENERAL	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		04. 2.5L V6 LEAD	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		05. 2.4L DOHC MELCO	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		06. 2.4L DOHC A/T MELCO	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		07. 2.0L DOHC A/T LEAD	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		08. 2.0L DOHC M/T MELCO	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		09. 2.0L DOHC M/T MELCO	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
	02.AUTOMATIC TRANSAXLE	01. TCU for 2.5L/2.7L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		02. TCU for 2.4L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		03. TCU for 2.0L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
	03.ANTI-LOCK SYSTEM	01. MANDO	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		02. BOSCH	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		04.SRS-AIRBAG		1、 Read trouble codes 2、 Data Stream
	41.OPTIMA(MAGENTIS) 2000-01	01.ENGINE CONTROL	01. 2.5L V6 EURO-III	1、 Read trouble codes 2、 Data Stream 3、 Actuations
02. 2.5L V6 GENERAL			1、 Read trouble codes 2、 Data Stream 3、 Actuations	
03. 2.5L V6 LEAD			1、 Read trouble codes 2、 Data Stream 3、 Actuations	
04. 2.4L DOHC MELCO			1、 Read trouble codes 2、 Data Stream 3、 Actuations	
05. 2.4L DOHC A/T MELCO			1、 Read trouble codes 2、 Data Stream 3、 Actuations	
06. 2.0L DOHC A/T LEAD			1、 Read trouble codes 2、 Data Stream 3、 Actuations	
07. 2.0L DOHC M/T MELCO			1、 Read trouble codes 2、 Data Stream 3、 Actuations	
08. 2.0L DOHC M/T LEAD			1、 Read trouble codes 2、 Data Stream 3、 Actuations	

AUTOBD NETWORK CO.,LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China

Tel/Fax: 0086-20-62853799

Website: www.autoibd.net



	02.AUTOMATIC TRANSAXLE	01. TCU for 2.5L/2.7L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02. TCU for 2.4L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		03. TCU for 2.0L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
42.ELAN 1998	04.SRS-AIRBAG		1、 Read trouble codes 2、 Data Stream
	01.ENGINE CONTROL		1、 Read trouble codes 2、 Data Stream 3、 Actuations
43.ELAN 1997	02.SRS-AIRBAG		1、 Read trouble codes
	01.ENGINE CONTROL		1、 Read trouble codes 2、 Data Stream 3、 Actuations
44.POTENTIA ALL	01.ENGINE CONTROL	01. 2.0L DOHC(HFM) UNLEAD	1、 Read trouble codes 2、 Data Stream
		02. 2.0L DOHC(HFM) LEAD	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream
	03.ANTI-LOCK BRAKE SYSTEM		
45.ENTERPRISE ALL	04.SRS-AIRBAG		
	01.ENGINE CONTROL	01. 2.5L GASOLINE J5D	1、 Read trouble codes 2、 Data Stream
		02. 3.0L GASOLINE JED	1、 Read trouble codes 2、 Data Stream
		03. OBD-II 98-99MY	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes
	03.ANTI-LOCK BRAKE SYSTEM	01. 3.0L GASOLINE JED	1、 Read trouble codes 2、 Data Stream
02. 3.6L GASOLINE J6D		1、 Read trouble codes 2、 Data Stream	
04.SRS-AIRBAG		1、 Read trouble codes	
46.CARNIVAL(SEDAN)	01.ENGINE CONTROL	01.3.5L GASOLINE M/EAST	1、 Read trouble codes 2、 Data Stream 3、 Actuations

46. CARNIVAL(SEDAN)
AUTOBD NETWORK CO.,LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China
Tel/Fax: 0086-20-62853799 **Website:** www.autoibd.net



2003		02.2.5L V6 EURO-III		
		03.2.5L GASOLINE(EUROPE) KV6	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		04.2.4L/2.5L GASOLINE(GEN) KV6	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		05.2.9L DIESEL C/RALL	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
	02.AUTOMATIC TRANSAXLE		01. 3.5L GASOLINE M/EAST	1、 Read trouble codes 2、 Data Stream 3、 Actuations
			02. GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations
			03. DIESEL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	03.ANTI-LOCK SYSTEM	BRAKE	01. ABS	1、 Read trouble codes 2、 Data Stream 3、 Actuations
			02. ABS EURO-III	1、 Read trouble codes 2、 Data Stream 3、 Actuations
			03. ABS C/RALL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
04.SRS-AIRBAG			1、 Read trouble codes 2、 Data Stream	
47.CARNIVAL(SEDONA) 2002	01.ENGINE CONTROL	01. 2.5L V6 EURO-III		
		02. 2.5L GASOLINE(EUROPE) KV6	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		03. 2.4L/2.5L GASOLINE(GEN) KV6	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		04. 2.9L DIESEL C/RALL	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
	02.AUTOMATIC TRANSAXLE		01. GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations
			02. DIESEL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	03.ANTI-LOCK SYSTEM	BRAKE	01. ABS	1、 Read trouble codes 2、 Data Stream 3、 Actuations
			02. ABS EURO-III	1、 Read trouble codes 2、 Data Stream 3、 Actuations
			03. ABS C/RALL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG			1、 Read trouble codes 2、 Data Stream
48.CARNIVAL(SEDONA) 2000-01	01.ENGINE CONTROL	01. 2.5L GASOLINE(EUROPE) KV6	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
		02. 2.5L GASOLINE(GENERAL) KV6	1、 Read trouble codes 2、 Data Stream 3、 Actuations	
02.AUTOMATIC TRANSAXLE			01. TCU(GENERAL) GAS	1、 Read trouble codes 2、 Data Stream 3、 Actuations
			02. TCU(EUROPE) GAS	1、 Read trouble codes 2、 Data Stream 3、 Actuations

AUTOBD NETWORK CO.,LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China

Tel/Fax: 0086-20-62853799

Website: www.autobd.net



	03.ANTI-LOCK BRAKE SYSTEM	03. TCU(GENERAL) DIESEL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		04. TCU(EUROPE) DIESEL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		01. ABS(EUROPE)	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02. ABS(GENERAL) GAS	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG	03. ABS(GENERAL) DIESEL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		01. A/BAG(EUROPE)	1、 Read trouble codes 2、 Data Stream
		02. A/BAG(GENERAL)	1、 Read trouble codes 2、 Data Stream
49.CARNIVAL(SEDONA) 1998-99	01.ENGINE CONTROL	01. 2.5L GASOLINE(EUROPE) KV6	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02. 2.5L GASOLINE(GENERAL) KV6	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	02.AUTOMATIC TRANSAXLE	01. TCU(GENERAL) GAS	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02. TCU(EUROPE) GAS	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		03. TCU(GENERAL) DIESEL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		04. TCU(EUROPE) DIESEL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	03.ANTI-LOCK BRAKE SYSTEM	01. ABS(EUROPE)	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02. ABS(GENERAL) GAS	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		03. ABS(GENERAL) DIESEL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG	01. A/BAG(EUROPE)	1、 Read trouble codes 2、 Data Stream
		02. A/BAG(GENERAL)	1、 Read trouble codes 2、 Data Stream
	50.RETONA ALL	01.ENGINE CONTROL	01. 2.0L GASOLINE
02. 2.0L DIESEL RF-TCI			1、 Read trouble codes 2、 Data Stream 3、 Actuations
02.AUTOMATIC TRANSAXLE			1、 Read trouble codes 2、 Data Stream
03.ANTI-LOCK BRAKE SYSTEM			1、 Read trouble codes 2、 Data Stream 3、 Actuations
04.SRS-AIRBAG			

AUTOBD NETWORK CO.,LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China

Tel/Fax: 0086-20-62853799

Website: www.autoibd.net



51.JOICE ALL	01.ENGINE CONTROL	01. 2.0L GASOLINE	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02. 2.0L GASOLINE IMM	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		03. 2.0L GASOLINE EURO-III	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
52.TOWNER ALL	01. ENGINE CONTROL		1、 Read trouble codes 2、 Data Stream 3、 Actuations
53.PREGIO 2003	01. ENGINE CONTROL		1、 Read trouble codes 2、 Data Stream 3、 Actuations
54.PREGIO 2002	01. ENGINE CONTROL		1、 Read trouble codes 2、 Data Stream 3、 Actuations
55.FRONTIER 2003	01. ENGINE CONTROL		1、 Read trouble codes 2、 Data Stream 3、 Actuations
56.FRONTIER 2002	01. ENGINE CONTROL		1、 Read trouble codes 2、 Data Stream 3、 Actuations
57.SORENTO 2003	01. ENGINE CONTROL	01 ENGINE DIESEL(A-ENG)	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02 3.5L V6 GASOLINE ALL	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		03 2.4L GASOLINE UNLEAD	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		04 2.4L GASOLINE LEAD	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	02.AUTOMATIC TRANSAXLE		1、 Read trouble codes 2、 Data Stream 3、 Actuations
58.SPECTRA ALL	01. ENGINE CONTROL	03.ANTI-LOCK BRAKE SYSTEM	
		04.SRS-AIRBAG	1、 Read trouble codes 2、 Data Stream
		01.Eng. 1.5/1.6(Non Immo)	1、 Read trouble codes 2、 Data Stream
		02.Eng. 1.5/1.6(W/Immo)	1、 Read trouble codes 2、 Data Stream
		03.Eng. 1.5/1.6 lead	1、 Read trouble codes 2、 Data Stream

AUTOBD NETWORK CO., LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China
 Tel/Fax: 0086-20-62853799 Website: www.autoibd.net

1、 Read trouble codes 2、 Data Stream



	TRANSAXLE		
	03.ANTI-LOCK BRAKE SYSTEM		1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04.SRS-AIRBAG		1、 Read trouble codes
59.CAPITAL AL	01 ENGINE CONTROL	01 CAPITAL SOHC	1、 Read trouble codes
		02 CAPITAL DOHC	1、 Read trouble codes
60.CONCORD ALL	01 ENGINE CONTROL	01 CONCORD 1.8 SOHC	1、 Read trouble codes
		02 CONCORD 2.0 SOHC	1、 Read trouble codes
		03 CONCORD 2.0 DOHC	1、 Read trouble codes
		04 CONCORD LPG TAXI	1、 Read trouble codes
61.CREDOS ALL	01 ENGINE CONTROL	01 1.8 DOHC	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02 2.0 SOHC	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		03 2.0 DOHC	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		04 1.8 LPG	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		05 2.0 LPG	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		06 CREDOS II 1.8 DOHC	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		07 CREDOS II 2.0 SOHC	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		08 CREDOS II 2.0 DOHC	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		09 CREDOS V6	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE	01 1.8 DOHC	1、 Read trouble codes
		02 2.0 SOHC	1、 Read trouble codes
		03 2.0 DOHC	1、 Read trouble codes
		04 1.8 LPG	1、 Read trouble codes
		05 2.0 LPG	1、 Read trouble codes
		06 CREDOS II 1.8 DOHC	1、 Read trouble codes 2、 Data Stream 3、 Actuations

AUTOBD NETWORK CO.,LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China

Tel/Fax: 0086-20-62853799

Website: www.autobd.net



		07 CREDOS II 2.0 SOHC	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		08 CREDOS II 2.0 DOHC	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		09 CREDOS V6	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	03 SRS ARIBAG	01 1.8 DOHC	1、 Read trouble codes 2、 Data Stream
		02 2.0 SOHC	1、 Read trouble codes 2、 Data Stream
		03 2.0 DOHC	1、 Read trouble codes 2、 Data Stream
		04 CREDOS II 1.8 DOHC	1、 Read trouble codes 2、 Data Stream
		05 CREDOS II 2.0 SOHC	1、 Read trouble codes 2、 Data Stream
		06 CREDOS II 2.0 DOHC	1、 Read trouble codes 2、 Data Stream
		07 CREDOS V6	1、 Read trouble codes 2、 Data Stream
62.CARSTAR ALL	1 ENGINE CONTROL	01 CARSTAR DOHC	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02 CARSTAR FBM(LPG)	1、 Read trouble codes 2、 Data Stream
	02.AUTOMATIC TRANSAXLE	01 CARSTAR DOHC	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02 CARST AR FBM(LPG)	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	03.ANTI-LOCK BRAKE SYSTEM	01 CARSTAT DOHC	1、 Read trouble codes 2、 Data Stream 3、 Actuations
		02 CARSTAR FBM(LPG)	1、 Read trouble codes 2、 Data Stream 3、 Actuations
	04 SRS AIRBAG	01 CARSTAT DOHC	1、 Read trouble codes 2、 Data Stream
		02 CARSTAR FBM(LPG)	1、 Read trouble codes 2、 Data Stream

AUTOBD NETWORK CO.,LTD

ADD: 5/F, Guangzhou 863 Industrialization Promotion Center, Guangzhou Civilion Scien-tech Park, Taihe Town, Guangzhou, China

Tel/Fax: 0086-20-62853799

Website: www.autoobd.net