

## Renault Testable Coverage

Now making new software, please waiting !!!

Vehicle Type	System	Version Info.	Read Fault Code	Clear Fault Code	Read DataStream	Actuation	读配置	Configuration	Orders
TWINGO	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Network Unit	√	√	√	√	√			
	SRS/Pretension	√	√	√	√	√			
TWINGO phase 2	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Network Unite	√	√	√	√	√			
	SRS/Pretension	√	√	√	√	√			
CLIO	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	SRS/Pretension	√	√	√	√	√			
CLIO 2	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AC	√	√	√	√	√			

	AT	√	√	√	√	√			
	Engine Warning Alarm System Warning Alarm System	√	√	√	√	√			√
	Diesel oil injection	√	√	√	√	√			
	Netw ork Unit	√	√	√	√	√			
	SRS / Warning Alarm System	√	√	√	√	√			
CLIO II PH 2	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AC	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Diesel oil injection	√	√	√	√	√			
	Netw ork Unit	√	√	√	√	√			
	SRS/Pretension	√	√	√	√	√		√	
	Discharge Indicator Lighter	√	√	√	√	√			
THALIA/SYMBL	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AC	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Netw ork Unit	√	√	√	√	√			
	SRS/ Warning Alarm System	√	√	√	√				
CLIO V6	Gasoline injection system	√	√	√	√	√			
	AC	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Netw ork Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√	√			
CLIO V6 PH 2	Gasoline injection system	√	√	√	√	√			

	AC	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√	√			
MEGANE/SCENIC	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√	√			
	AC	√	√	√	√	√			
	AT	√	√	√	√	√		√	√
	Engine Warning Alarm System	√	√	√	√	√			√
	Diesel oil injection	√	√	√	√		√	√	
	Network Unit	√	√	√	√	√		√	
	SRS/ Warning Alarm System	√	√	√	√				
	Engine hood control	√	√	√	√	√			
	Tyre System	√	√	√	√	√			
MEGANE II	Gasoline injection system	√	√	√	√	√			
	ABS	√	√	√	√	√			
	VAPS	√	√	√	√				
	KOM	√	√	√	√	√			
	SRS/ Warning Alarm System	√	√	√	√				
	Passenger space control unit	√	√	√	√	√			
	Valve code programming	√	√	√	√	√			
	Diesel oil injection	√	√	√	√	√			
AT	√	√	√	√	√	√			
SENIC II	Parking brake	√	√	√	√	√			
	ABS	√	√	√	√	√			
	VAPS	√	√	√	√				
	KOM	√	√	√	√		√		
	SRS/ Warning Alarm System	√	√	√	√				
	AC	√	√	√	√	√	√		

	Valve code programming	√	√	√	√	√	√		
	Diesel oil injection	√	√	√	√	√			
	Anti-theft control unit	√	√	√	√	√	√		
MODUS	Diesel injectionDiesel oil injection	√	√	√	√	√			
	ABS	√	√	√	√	√			
	VAPS	√	√	√	√		√		
	KOM	√	√	√	√	√	√		
	SRS/Warning Alarm System	√	√	√	√		√		
	Valve code programming	√	√	√	√		√		
	Anti-theft control unit	√	√	√	√	√	√		
LAUGNA	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√	√			
	AC	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	KOM	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			
	Diesel oil injection	√	√	√	√	√			
	SRS/ Warning Alarm System	√	√	√	√				√
LAGUNA phae 2	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√	√			
	AC	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	KOM	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			
	Diesel oil injection	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
LAGUNA II	Gasoline injection system	√	√	√	√	√	√		√

	ABS	√	√	√	√	√			
	AC	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	KOM	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Diesel oil injection	√	√	√	√	√			√
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				√
	Door management	√	√	√	√	√			
	Discharge Indicator Lighter	√	√	√	√	√			
	Parking assistance	√	√	√	√				
	Tyre System	√	√	√	√	√			√
	Gasoline injection system	√	√	√	√	√	√		
SAFRANE	ABS	√	√	√	√				
	AC	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	KOM	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
	Door management	√	√	√	√	√			
	Discharge Indicator Lighter	√	√	√	√	√			
	Gasoline injection system	√	√	√	√	√	√		
VEL SATIS	ABS	√	√	√	√	√			
	AC	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	KOM	√	√	√	√	√			
	AT	√	√	√	√	√			

	Engine Warning Alarm System	√	√	√	√	√			
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
	Door management	√	√	√	√	√			
	Discharge Indicator Lighter	√	√	√	√	√			
	Tyre System	√	√	√	√	√			
	Parking brake	√	√	√	√	√			
AVANTIME	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AC	√	√	√	√	√			
	KOM	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
	Discharge Indicator Lighter	√	√	√	√	√			
ESPACE	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AC	√	√	√	√	√			
	KOM	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			
	Diesel oil injection	√	√	√	√		√	√	
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
	Door management	√	√	√	√	√			
	Discharge Indicator Lighter	√	√	√	√	√			
ESPACE IV	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√			√	

	AC	√	√	√	√	√	√		
	VAPS	√	√	√	√	√	√		
	KOM	√	√	√	√	√	√	√	
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√	√	√	
	Diesel oil injection	√	√	√	√	√			√
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
	Door management	√	√	√	√	√			
	Discharge Indicator Lighter	√	√	√	√	√			
	Tyre System	√	√	√	√	√			
	Parking assistance	√	√	√	√				
	Parking brake	√	√	√	√	√			
KANGOO	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AC	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Diesel oil injection	√	√	√	√	√			
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
KANGOO MUX	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Diesel oil injection	√	√	√	√	√			
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
TRAFIC	Gasoline injection system	√	√	√	√	√	√		

	Engine Warning Alarm System	√	√	√	√	√			√
	SRS/Warning Alarm System	√	√	√	√				
TRAFIC II	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	Engine Warning Alarm System	√	√	√	√	√			√
	Netw ork Unit	√	√	√	√	√			
	SRS/Netw ork Unit	√	√	√	√				
MASTER	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	Engine Warning Alarm System	√	√	√	√	√			√
	Netw ork Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
MASTER RWD	Engine Warning Alarm System	√	√	√	√	√			√
	Netw ork Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
MASCOTT	Engine Warning Alarm System	√	√	√	√	√			√
	Netw ork Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
SPIDER	Gasoline injection system	√	√	√	√	√			
	Warning Alarm System	√	√	√	√	√			√
	SRS/Warning Alarm System	√	√	√	√				
SUPER 5	Gasoline injection system	√	√	√	√	√	√		
EXTRA	Gasoline injection system	√	√	√	√	√	√		
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	SRS/Warning Alarm System	√	√	√	√				
R19	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AT	√	√	√	√	√			

	Engine Warning System	√	√	√	√	√			√
R21/SAVANNA	Gasoline injection system	√	√	√	√	√	√		
R25	Gasoline injection system	√	√	√	√	√	√		
ALPINE	Gasoline injection system	√	√	√	√	√	√		