

Renault Testable Coverage

Version: 20.00

Updated date: March 18<sup>th</sup> 2007

Updated date: March 18 <sup>th</sup> 2007 Vehicle Type	System	Version Info.	Read Fault Code	Clear Fault Code	Read DataStream	Actuation	读配置	Configuration	Orders
TWINGO	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Network Unit	√	√	√	√	√			
	SRS/Pretension	√	√	√	√	√			
TWINGO phase 2	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Network Unite	√	√	√	√	√			
	SRS/Pretension	√	√	√	√	√			
CLIO	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√

	SRS/Pretension	√	√	√	√	√			
CLIO 2	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AC	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm SystemEngine Warning Alarm System	√	√	√	√	√			√
	Diesel oil injection	√	√	√	√	√			
	Network Unit	√	√	√	√	√			
	SRS / Warning Alarm System	√	√	√	√	√			
CLIO II PH 2	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AC	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Diesel oil injection	√	√	√	√	√			
	Network Unit	√	√	√	√	√			
	SRS/Pretension	√	√	√	√	√		√	
Discharge Indicator Lighter	√	√	√	√	√				
THALIA/SYMBL	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AC	√	√	√	√	√			
	AT	√	√	√	√	√			

	Engine Warning Alarm System	√	√	√	√	√			√
	Network Unit	√	√	√	√	√			
	SRS/ Warning Alarm System	√	√	√	√				
CLIO V6	Gasoline injection system	√	√	√	√	√			
	AC	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√	√			
CLIO V6 PH 2	Gasoline injection system	√	√	√	√	√			
	AC	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√	√			
MEGANE/SCENIC	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√	√			
	AC	√	√	√	√	√			
	AT	√	√	√	√	√		√	√
	Engine Warning Alarm System	√	√	√	√	√			√
	Diesel oil injection	√	√	√	√		√	√	
	Network Unit	√	√	√	√	√		√	
	SRS/ Warning Alarm System	√	√	√	√				
	Engine hood control	√	√	√	√	√			
Tyre System	√	√	√	√	√				
MEGANE II	Gasoline injection system	√	√	√	√	√			

	ABS	√	√	√	√	√			
	VAPS	√	√	√	√				
	KOM	√	√	√	√	√			
	SRS/ Warning Alarm System	√	√	√	√				
	Passenger space control unit	√	√	√	√	√			
	Valve code programming	√	√	√	√	√			
	Diesel oil injection	√	√	√	√	√			
	AT	√	√	√	√	√	√		
SENIC II	Parking brake	√	√	√	√	√			
	ABS	√	√	√	√	√			
	VAPS	√	√	√	√				
	KOM	√	√	√	√		√		
	SRS/ Warning Alarm System	√	√	√	√				
	AC	√	√	√	√	√	√		
	Valve code programming	√	√	√	√	√	√		
	Diesel oil injection	√	√	√	√	√			
	Anti-theft control unit	√	√	√	√	√	√		
MODUS	Diesel injectionDiesel oil injection	√	√	√	√	√			
	ABS	√	√	√	√	√			
	VAPS	√	√	√	√		√		
	KOM	√	√	√	√	√	√		
	SRS/Warning Alarm System	√	√	√	√		√		
	Valve code programming	√	√	√	√		√		
	Anti-theft control unit	√	√	√	√	√	√		

LAUGNA	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√	√			
	AC	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	KOM	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			
	Diesel oil injection	√	√	√	√	√			
	SRS/ Warning Alarm System	√	√	√	√				√
LAGUNA phae 2	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√	√			
	AC	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	KOM	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			
	Diesel oil injection	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
LAGUNA II	Gasoline injection system	√	√	√	√	√	√		√
	ABS	√	√	√	√	√			
	AC	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	KOM	√	√	√	√	√			
	AT	√	√	√	√	√			

	Engine Warning Alarm System	√	√	√	√	√			√
	Diesel oil injection	√	√	√	√	√			√
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				√
	Door management	√	√	√	√	√			
	Discharge Indicator Lighter	√	√	√	√	√			
	Parking assistance	√	√	√	√				
	Tyre System	√	√	√	√	√			√
SAFRANE	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AC	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	KOM	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
	Door management	√	√	√	√	√			
	Discharge Indicator Lighter	√	√	√	√	√			
VEL SATIS	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√	√			
	AC	√	√	√	√	√			
	VAPS	√	√	√	√	√			
	KOM	√	√	√	√	√			
	AT	√	√	√	√	√			

	Engine Warning Alarm System	√	√	√	√	√			
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
	Door management	√	√	√	√	√			
	Discharge Indicator Lighter	√	√	√	√	√			
	Tyre System	√	√	√	√	√			
	Parking brake	√	√	√	√	√			
AVANTIME	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AC	√	√	√	√	√			
	KOM	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
ESPACE	Discharge Indicator Lighter	√	√	√	√	√			
	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AC	√	√	√	√	√			
	KOM	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			
	Diesel oil injection	√	√	√	√		√	√	
Network Unit	√	√	√	√	√				

	SRS/Warning Alarm System	√	√	√	√				
	Door management	√	√	√	√	√			
	Discharge Indicator Lighter	√	√	√	√	√			
ESPACE IV	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√			√	
	AC	√	√	√	√	√	√		
	VAPS	√	√	√	√	√	√		
	KOM	√	√	√	√	√	√	√	
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√	√	√	
	Diesel oil injection	√	√	√	√	√			√
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
	Door management	√	√	√	√	√			
	Discharge Indicator Lighter	√	√	√	√	√			
	Tyre System	√	√	√	√	√			
	Parking assistance	√	√	√	√				
	Parking brake	√	√	√	√	√			
KANGOO	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AC	√	√	√	√	√			
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Diesel oil injection	√	√	√	√	√			

	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
KANGOO MUX	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	Diesel oil injection	√	√	√	√	√			
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
TRAFIC	Gasoline injection system	√	√	√	√	√	√		
	Engine Warning Alarm System	√	√	√	√	√			√
	SRS/Warning Alarm System	√	√	√	√				
TRAFIC II	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	Engine Warning Alarm System	√	√	√	√	√			√
	Network Unit	√	√	√	√	√			
	SRS/Network Unit	√	√	√	√				
MASTER	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	Engine Warning Alarm System	√	√	√	√	√			√
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
MASTER RWD	Engine Warning Alarm System	√	√	√	√	√			√
	Network Unit	√	√	√	√	√			

	SRS/Warning Alarm System	√	√	√	√				
MASCOTT	Engine Warning Alarm System	√	√	√	√	√			√
	Network Unit	√	√	√	√	√			
	SRS/Warning Alarm System	√	√	√	√				
SPIDER	Gasoline injection system	√	√	√	√	√			
	Warning Alarm System	√	√	√	√	√			√
	SRS/Warning Alarm System	√	√	√	√				
SUPER 5	Gasoline injection system	√	√	√	√	√	√		
EXTRA	Gasoline injection system	√	√	√	√	√	√		
	AT	√	√	√	√	√			
	Engine Warning Alarm System	√	√	√	√	√			√
	SRS/Warning Alarm System	√	√	√	√				
R19	Gasoline injection system	√	√	√	√	√	√		
	ABS	√	√	√	√				
	AT	√	√	√	√	√			
	Engine Warning System	√	√	√	√	√			√
R21/SAVANNA	Gasoline injection system	√	√	√	√	√	√		
R25	Gasoline injection system	√	√	√	√	√	√		
ALPINE	Gasoline injection system	√	√	√	√	√	√		